

# Operator's Manual

Firmware V6.21 and higher



SWISS  MADE



## Customer Support

Swan and its representatives maintain a fully trained staff of technical specialists around the world. For any technical question, contact your nearest Swan representative, or the manufacturer:

Swan Analytische Instrumente AG  
Studbachstrasse 13  
8340 Hinwil  
Switzerland

Internet: [www.swan.ch](http://www.swan.ch)  
E-mail: [support@swan.ch](mailto:support@swan.ch)

## Document status

<b>Title:</b>	Operator's Manual for AMI Codes-II O3	
<b>ID:</b>	A-96.250.881	
<b>Revision</b>	<b>Issue</b>	
00	Jan. 2018	First edition
01	June 2020	Mainboard V2.6

## Table of Contents

<b>1. Safety Instructions</b>	<b>6</b>
1.1. Warning Notices	7
1.2. General Safety Regulations	9
1.3. Restrictions for use	10
<b>2. Product Description</b>	<b>11</b>
2.1. Instrument Specification	15
2.2. Instrument Overview	17
<b>3. Installation</b>	<b>18</b>
3.1. Installation Checklist	18
3.2. Mounting of Instrument Panel	19
3.3. Connecting Sample and Waste	19
3.3.1 FEP Tube at Sample Inlet	19
3.3.2 FEP Tube at Sample Outlet	20
3.4. Installation of Flow Cell	21
3.5. Electrical Connections	22
3.5.1 Connection Diagram	24
3.5.2 Power Supply	25
3.5.3 Opening the peristaltic pump housing	26
3.6. Input	27
3.7. Relay Contacts	27
3.7.1 Alarm Relay	27
3.7.2 Relay 1 and 2	28
3.8. Signal Outputs	30
3.8.1 Signal Output 1 and 2 (current outputs)	30
3.9. Interface Options	30
3.9.1 Signal Output 3	31
3.9.2 Profibus, Modbus Interface	31
3.9.3 HART Interface	32
3.9.4 USB Interface	32
<b>4. Instrument Setup</b>	<b>33</b>
4.1. Prepare Reagents	33
4.2. Peristaltic Pump	33
4.3. Establish Sample Flow	34
4.4. Fill or Flush Reagent System	35
4.5. Programming	35
4.6. Calibration	36
4.7. Commissioning	36

<b>5. Operation</b>	<b>37</b>
5.1. Keys	37
5.2. Display	38
5.3. Software Structure	39
5.4. Changing Parameters and values	40
<b>6. Maintenance</b>	<b>41</b>
6.1. Maintenance Schedule	41
6.2. Stop of Operation for Maintenance	42
6.3. Refill or replace Reagents	43
6.3.1 Reagents for measuring Ozone	45
6.4. Verification	46
6.5. Calibration	50
6.6. Cleaning the Photometer	51
6.7. Cleaning the Flow Cell	52
6.7.1 Disassemble the Flow Cell	52
6.7.2 Assemble the Flow Cell	53
6.8. Tube Replacement	54
6.8.1 Replace the Pump Tubes	54
6.9. Longer Stop of Operation	56
<b>7. Troubleshooting</b>	<b>57</b>
7.1. General Instructions	57
7.2. Calibration Errors	58
7.2.1 Process Calibration DIS	58
7.3. Verification Errors	58
7.4. Error List	59
7.5. Replacing Fuses	62
<b>8. Program Overview</b>	<b>63</b>
8.1. Messages (Main Menu 1)	63
8.2. Diagnostics (Main Menu 2)	64
8.3. Maintenance (Main Menu 3)	65
8.4. Operation (Main Menu 4)	66
8.5. Installation (Main Menu 5)	67
<b>9. Program List and Explanations</b>	<b>69</b>
1 Messages	69
2 Diagnostics	69
3 Maintenance	71
4 Operation	72
5 Installation	73

---

<b>10. Material Safety Data Sheets</b>	<b>85</b>
10.1. Reagents	85
<b>11. Default Values</b>	<b>86</b>
<b>12. Index</b>	<b>89</b>
<b>13. Notes</b>	<b>91</b>

# Operator's Manual

This document describes the main steps for instrument setup, operation and maintenance.

## 1. Safety Instructions

<b>General</b>	<p>The instructions included in this section explain the potential risks associated with instrument operation and provide important safety practices designed to minimize these risks.</p> <p>If you carefully follow the information contained in this section, you can protect yourself from hazards and create a safer work environment.</p> <p>More safety instructions are given throughout this manual, at the respective locations where observation is most important. Strictly follow all safety instructions in this publication.</p>
<b>Target audience</b>	<p>Operator: Qualified person who uses the equipment for its intended purpose.</p> <p>Instrument operation requires thorough knowledge of applications, instrument functions and software program as well as all applicable safety rules and regulations.</p>
<b>OM Location</b>	<p>Keep the AMI Operator's Manual in proximity of the instrument.</p>
<b>Qualification, Training</b>	<p>To be qualified for instrument installation and operation, you must:</p> <ul style="list-style-type: none"><li>♦ read and understand the instructions in this manual as well as the Material Safety Data Sheets.</li><li>♦ know the relevant safety rules and regulations.</li></ul>

## 1.1. Warning Notices

The symbols used for safety-related notices have the following meaning:



### **DANGER**

Your life or physical wellbeing are in serious danger if such warnings are ignored.

- ♦ Follow the prevention instructions carefully.



### **WARNING**

Severe injuries or damage to the equipment can occur if such warnings are ignored.

- ♦ Follow the prevention instructions carefully.



### **CAUTION**

Damage to the equipment, minor injury, malfunctions or incorrect process values can be the consequence if such warnings are ignored.

- ♦ Follow the prevention instructions carefully.

### **Mandatory Signs**

The mandatory signs in this manual have the following meaning:



Safety goggles



Safety gloves

**Warning Signs**     The warning signs in this manual have the following meaning:



Electrical shock hazard



Corrosive



Harmful to health



Flammable



Warning general



Attention general



## 1.2. General Safety Regulations

### **Legal Requirements**

The user is responsible for proper system operation. All precautions must be followed to ensure safe operation of the instrument.

### **Spare Parts and Disposables**

Use only official SWAN spare parts and disposables. If other parts are used during the normal warranty period, the manufacturer's warranty is voided.

### **Modifications**

Modifications and instrument upgrades shall only be carried out by an authorized Service Technician. SWAN will not accept responsibility for any claim resulting from unauthorized modification or alteration.

### **WARNING**

#### **Electrical Shock Hazard**



If proper operation is no longer possible, the instrument must be disconnected from all power lines, and measures must be taken to prevent inadvertent operation.

- ♦ To prevent from electrical shock, always make sure that the ground wire is connected.
- ♦ Service shall be performed by authorized personnel only.
- ♦ Whenever electronic service is required, disconnect instrument power and power of devices connected to.
  - relay 1,
  - relay 2,
  - alarm relay

### **WARNING**



For safe instrument installation and operation you must read and understand the instructions in this manual.

### **WARNING**



Only SWAN trained and authorized personnel shall perform the tasks described in this document.

### 1.3. Restrictions for use

The sample must not contain any particles, which may block the flow cell. Sufficient sample flow is coercive for the correct function of the instrument.

#### **WARNING**



#### **Health hazard**

Some reagents are etching and can cause severe burns or eye damage.

- ♦ For safe handling of the reagents you must read and understand the instructions in this manual, as well as the Material Safety Data Sheets (MSDS)

#### **Download MSDS**

The current Material Safety Data Sheets (MSDS) for the below listed Reagents are available for downloading at **[www.swan.ch](http://www.swan.ch)**.

- ♦ OXYCON ON-LINE DPD
- ♦ OXYCON ON-LINE Ozone

## 2. Product Description

<b>Application Range</b>	<p>The AMI Codes-II O3 analyzer is a complete monitoring system for the automatic, continuous measurement and dosing control of ozone based on the DPD colorimetric method according to DIN 38408-3:2011-4.</p> <p>It can be used for measuring ozone in pharma water and industrial high purity water applications.</p>
<b>Signal Outputs</b>	<p>Two signal outputs programmable for measured values (freely scalable, linear or bilinear) or as continuous control output (control parameters programmable).</p> <p>Current loop: 0/4–20 mA Maximal burden: 510 <math>\Omega</math></p> <p>Third signal output available as an option. The third signal output can be operated as a current source or as a current sink (selectable via switch).</p>
<b>Relays</b>	<p>Two potential-free contacts programmable as limit switches for measuring values, controllers or timer for system cleaning with automatic hold function. Both contacts can be set as normally open or normally closed with a jumper.</p> <p>Maximum load: 1 A/250 VAC</p>
<b>Alarm Relay</b>	<p>One potential free contact.</p> <p>Alternatively:</p> <ul style="list-style-type: none"><li>♦ Open during normal operation, closed on error and loss of power.</li><li>♦ Closed during normal operation, open on error and loss of power.</li></ul> <p>Summary alarm indication for programmable alarm values and instrument faults.</p>
<b>Input</b>	<p>For potential-free contact to freeze the measuring value or to interrupt control in automated installations (hold function or remote-off).</p>
<b>Safety Features</b>	<p>No data loss after power failure. All data is saved in non-volatile memory. Overvoltage protection of inputs and outputs. Galvanic separation of measuring inputs from signal outputs.</p>

**Communication Interface (optional)**

- ◆ USB Interface for logger download
- ◆ Third signal output (can be used in parallel to the USB interface)
- ◆ RS485 with Fieldbus protocol Modbus or Profibus DP
- ◆ HART interface


**Special features**

Specific features for pharmaceutical industry: Audit Trail, performance verification and an optional validation package (IQ, OQ, PQ).

**Fluidics**

The sample flows through the sample inlet [F] into the constant head [A]. Adjust the flow regulating valve [D] so that always a small part of the sample flows through the overflow tube [B] into the drain [H]. A part of the sample flows through the photometer inlet [C] into the mixing chamber [E], where reagent [K] is added and mixed with the sample. The mixed sample then flows through the coiled tube to the photometer [N]. Shortly before entering the photometer, reagent [J] is added to the mixture through a T-piece.

In the photometer [N], the ozone concentration is measured. After the measurement, the sample flows through the outlet of the photometer where it is aerated through air inlet [P] to generate bubbles. Then the sample flows through the bubble detector [M] into the photometer drain [I].




- |                                    |                                       |
|------------------------------------|---------------------------------------|
| <b>A</b> Constant head             | <b>I</b> Photometer drain             |
| <b>B</b> Overflow tube             | <b>J</b> Oxycon on-line DPD reagent   |
| <b>C</b> Photometer inlet          | <b>K</b> Oxycon on-line Ozone reagent |
| <b>D</b> Flow regulating valve     | <b>L</b> Reagent level detector       |
| <b>E</b> Mixing chamber            | <b>M</b> Air bubble detector          |
| <b>F</b> Sample inlet              | <b>N</b> Photometer                   |
| <b>G</b> Filter vessel (no filter) | <b>O</b> Peristaltic pump             |
| <b>H</b> Constant head drain       | <b>P</b> Photometer air inlet         |

**Time  
 interval of a  
 measurement**

The measuring interval can be set between 5 and 10 minutes. The time sequence of a measurement with a measuring interval of 5 min is shown in the diagram below.

The blue bar represents the sample which flows continuously through the photometer. A short time before the measurement starts, a zero point measurement is performed. Then the peristaltic pump starts and a small portion of the reagents [J] and [K] is added. Shortly after, when the mixture is in the photometer, the sample is measured.



**J** OXYCON ON-LINE DPD reagent

**K** OXYCON ON-LINE Ozone reagent


Zero point measurement

Sample measurement

## 2.1. Instrument Specification


<b>Power Supply</b>	AC variant:	100–240 VAC ( $\pm 10\%$ ) 50/60 Hz ( $\pm 5\%$ )
	DC variant	10–36 VDC
	Power consumption:	max. 35 VA
<b>Transmitter specifications</b>	Housing:	aluminum, with a protection degree of IP 66 / NEMA 4X
	Ambient temperature:	–10 to +50 °C
	Storage and transport:	–30 to +85 °C
	Humidity:	10–90% rel., non condensing
<b>Sample requirements</b>	Display:	backlit LCD, 75 x 45 mm
	Flow rate:	min. 10 l/h
	Temperature:	5–50 °C
	Inlet pressure:	0.15–2 bar
	Outlet pressure:	pressure free
<b>Note:</b> No oil, no grease, no sand.		
<b>On-site requirements</b>	The analyzer site must permit connections to:	
	Sample inlet:	Serto PVDF 6 mm (1/4" thread) Tube 6x4 mm
	Sample outlet:	1/2" hose nozzle for flexible tube diam. 20x15 mm
<b>Ozone measurement</b>	Measuring range:	Accuracy:
	0–500 ppb	$\pm 1$ ppb or 5%, whichever is greater
	Limit of detection:	1 ppb
	Cycle time:	5–10 min

<b>Dimensions</b>	Panel:	stainless steel
	Dimensions:	400x850x200 mm
	Screws:	8 mm diameter
	Weight:	14.0 kg





## 2.2. Instrument Overview



### 3. Installation

#### 3.1. Installation Checklist


<b>On-site requirements</b>	<p>AC variant: 100–240 VAC (<math>\pm 10\%</math>), 50/60 Hz (<math>\pm 5\%</math>)</p> <p>DC variant: 10–36 VDC</p> <p>Power consumption: 35 VA maximum.</p> <p>Protective earth connection required.</p> <p>Sample line with sufficient sample flow and pressure (see <a href="#">Instrument Specification, p. 15</a>).</p>
<b>Installation</b>	<p>Mount the instrument in vertical position.</p> <p>Display should be at eye-level.</p> <p>Mount the constant head.</p> <p>Connect the sample and waste line. See <a href="#">Connecting Sample and Waste, p. 19</a></p>
<b>Electrical Wiring</b>	<p>Do not switch on the Instrument until all electrical connections have been completed.</p> <p>Connect all external devices like limit switches, current loops and pumps.</p> <p>Connect power cord. Do not switch on power yet.</p> <p>See <a href="#">Electrical Connections, p. 22</a>.</p>
<b>Reagents</b>	<p>Prepare reagents. See <a href="#">Refill or replace Reagents, p. 43</a>.</p> <p>Insert the suction lances.</p>
<b>Power-up</b>	<p>Lock pump tubes.</p> <p>Turn on the sample flow and wait until the flow cell is completely filled.</p> <p>Switch on power.</p> <p>Adjust sample flow.</p> <p>Start &lt;Fill system&gt;. See <a href="#">Fill or Flush Reagent System, p. 35</a>.</p>
<b>Instrument Setup</b>	<p>Program all parameters for external devices (interface, recorders, etc.). Program all parameters for instrument operation (limits, alarms, measuring interval).</p>

## 3.2. Mounting of Instrument Panel

The first part of this chapter describes the preparing and placing of the system for use.

- ♦ The instrument must only be installed by trained personnel.
- ♦ Mount the instrument in vertical position.
- ♦ For ease of operation mount it so that the display is at eye level.
- ♦ For the installation a kit containing the following installation material is available:
  - 4 Screws 8x60 mm
  - 4 Dowels
  - 4 Washers 8.4/24 mm

### Mounting requirements


The instrument is only intended for indoor installation.  
For dimensions see  16.

## 3.3. Connecting Sample and Waste

### 3.3.1 FEP Tube at Sample Inlet

Use plastic tube (FEP, PA, or PE 6 x 4 mm) to connect the sample line.

### Mounting of SERTO fitting



- A** Screw connection
- B** Compression ferrule
- C** Knurled nut
- D** Flexible tube

### 3.3.2 FEP Tube at Sample Outlet


#### WARNING



#### Risk of water pollution

The drain of the photometer outlet contains DPD.

- ♦ At no means recirculate it into the water system.



Connect the 1/2" tubes [F] to the hose nozzles [E] and place them into a pressure free drain with sufficient capacity.

### 3.4. Installation of Flow Cell




#### CAUTION

##### Fragile Part

Handle the constant head tube with care.

To avoid damage during the transport, the constant head tube [C] of the AMI Codes-II O3 is not installed.



To install the constant head tube proceed as follows:

- 1 Unpack the constant head tube [C].
- 2 Push the constant head tube into the flow cell block [E].
- 3 Put the constant head cover [A] onto the constant head tube.
- 4 Check if the overflow tube [B] is aligned with the upper Level mark.

### 3.5. Electrical Connections



#### WARNING


##### Risk of electrical shock

Do not perform any work on electrical components if the transmitter is switched on. Failure to follow safety instructions could result in serious injury or death.

- ♦ Always turn off power before manipulating electric parts.
- ♦ Grounding requirements: Only operate the instrument from a power outlet which has a ground connection.
- ♦ Make sure the power specification of the instrument corresponds to the power on site.

#### Cable thicknesses

In order to comply with IP66, use the following cable thicknesses



**A** PG 11 cable gland: cable  $\varnothing_{outer}$  5–10 mm

**B** PG 7 cable gland: cable  $\varnothing_{outer}$  3–6.5 mm

**C** PG 9 cable gland: cable  $\varnothing_{outer}$  4–8 mm

**Note:** Protect unused cable glands

#### Wire

- ♦ For Power and Relays: Use max. 1.5 mm<sup>2</sup> / AWG 14 stranded wire with end sleeves.
- ♦ For Signal Outputs and Input: Use 0.25 mm<sup>2</sup> / AWG 23 stranded wire with end sleeves.



### WARNING

#### External Voltage.

External supplied devices connected to relay 1 or 2 or to the alarm relay can cause electrical shocks

- ♦ Make sure that the devices connected to the following contacts are disconnected from the power before resuming installation.
  - relay 1
  - relay 2
  - alarm relay



### WARNING

To prevent from electrical shock, do not connect the instrument to the power unless the ground wire (PE) is connected.




### WARNING

The mains of the AMI Transmitter must be secured by a main switch and appropriate fuse or circuit breaker.



3.5.1 Connection Diagram



CAUTION



Use only the terminals shown in this diagram, and only for the mentioned purpose. Use of any other terminals will cause short circuits with possible corresponding consequences to material and personnel.




### 3.5.2 Power Supply



#### WARNING

##### Electrical shock hazard

Installation and maintenance of electrical parts must be performed by professionals. Always turn off power before manipulating electric parts.



- A** Power supply connector
- B** Neutral conductor, Terminal 2
- C** Phase conductor, Terminal 1
- D** Protective earth PE

**Note:** The protective earth wire (Ground) has to be connected to the grounding terminal.

#### Installation requirements


The installation must meet the following requirements.

- ♦ Mains cable to comply with standards IEC 60227 or IEC 60245; flammable rating FV1
- ♦ Mains equipped with an external switch or circuit-breaker
  - near the instrument
  - easily accessible to the operator
  - marked as interrupter for AMI Codes-II O3

### 3.5.3 Opening the peristaltic pump housing

For some electrical connections (see [Connection Diagram, p. 24](#)), it is necessary to open the housing of the peristaltic pump. To do this, proceed as follows:

- 1 Switch off the analyzer according to [Stop of Operation for Maintenance, p. 42](#).
- 2 Remove the protection cap and all pump tubes as described in [Dismount pump tubes, p. 55](#).
- 3 Unscrew the 4 screws of the peristaltic pump housing and remove the cover.
- 4 Disconnect the motor connector [A].



**A** Motor connector

- 5 Feed the cable into the housing through one of the PG7 cable glands (permissible cable thicknesses are specified in [Cable thicknesses, p. 22](#)).
- 6 Connect the cable to the terminal block of the peristaltic pump according to [Connection Diagram, p. 24](#).
- 7 Reassemble in reverse order.

### 3.6. Input

**Note:** Use only potential-free (dry) contacts.

The total resistance (sum of cable resistance and resistance of the relay contact) must be less than 50  $\Omega$ .

Terminals 30 and 31.

If the signal output is set to hold, the measurement is interrupted if input is active.

For programming see Menu Installation 5.3.4, p. 81.

### 3.7. Relay Contacts



#### 3.7.1 Alarm Relay

**Note:** Max. load 1 A/250 VAC

Alarm output for system errors.

Error codes see [Troubleshooting](#), p. 57.

**Note:** With certain alarms and certain settings of the AMI transmitter the alarm relay does not switch. The error, however, is shown on the display.

	Terminals	Description	Relay connection
<b>NC</b> <sup>1)</sup> Normally Closed	10/11	Active (opened) during normal operation. Inactive (closed) on error and loss of power.	
<b>NO</b> Normally Open	12/11	Active (closed) during normal operation. Inactive (opened) on error and loss of power.	





1) usual use


3.7.2 Relay 1 and 2

**Note:** Max. load 1 A/250 VAC

Relay 1 and 2 can be configured as normally open or as normally closed. Standard for both relays is normally open. To configure a Relay as normally closed, set the jumper in the upper position.

**Note:** Some error codes and the instrument status may influence the status of the relays described below.

Relay config.	Terminals	Jumper pos.	Description	Relay configuration
Normally Open	6/7: Relay 1 8/9: Relay 2		Inactive (opened) during normal operation and loss of power. Active (closed) when a programmed function is executed.	
Normally Closed	6/7: Relay 1 8/9: Relay 2		Inactive (closed) during normal operation and loss of power. Active (opened) when a programmed function is executed.	



- A Jumper set as normally open (standard setting)
- B Jumper set as normally closed

For programming see Menu Installation [5.3.2](#) and [5.3.3](#), p. 77.



### CAUTION

#### Risk of damage of the relays in the AMI Transmitter due to heavy inductive load.


Heavy inductive or directly controlled loads (solenoid valves, dosing pumps) may destroy the relay contacts.

- To switch inductive loads > 0.1 A use an AMI relay box available as an option or suitable external power relays.

### Inductive load

Small inductive loads (max 0.1 A) as for example the coil of a power relay can be switched directly. To avoid noise voltage in the AMI Transmitter it is mandatory to connect a snubber circuit in parallel to the load.


A snubber circuit is not necessary if an AMI relaybox is used.



- A** AC or DC power supply
- B** AMI Transmitter
- C** External power relay
- D** Snubber
- E** Power relay coil

### Resistive load


Resistive loads (max. 1 A) and control signals for PLC, impulse pumps and so on can be connected without further measures



- A** AMI Transmitter
- B** PLC or controlled pulse pump
- C** Logic

### Actuators

Actuators, like motor valves, are using both relays: One relay contact is used for opening, the other for closing the valve, i.e. with the 2 relay contacts available, only one motor valve can be controlled. Motors with loads bigger than 0.1 A must be controlled via external power relays or an AMI relay box.



- A** AC or DC power supply
- B** AMI Transmitter
- C** Actuator

### 3.8. Signal Outputs

#### 3.8.1 Signal Output 1 and 2 (current outputs)

**Note:** Max. burden 510  $\Omega$


*If signals are sent to two different receivers, use signal isolator (loop isolator).*

Signal output 1: Terminals 14 (+) and 13 (-)

Signal output 2: Terminals 15 (+) and 13 (-)

For programming see [Program List and Explanations](#), p. 69, Menu Installation

### 3.9 Interface Options



The slot for interfaces can be used to expand the functionality of the AMI instrument with either:


- ♦ Third signal output
- ♦ a Profibus or Modbus connection
- ♦ a HART connection
- ♦ a USB Interface

### 3.9.1 Signal Output 3

Terminals 38 (+) and 37 (-).

Requires the additional board for the third signal output 0/4–20 mA. The third signal output can be operated as a current source or as a current sink (switchable via switch [A]). For detailed information see the corresponding installation instruction.

**Note:** Max. burden 510  $\Omega$ .



Third signal output 0/4 - 20 mA PCB


**A** Operating mode selector switch

### 3.9.2 Profibus, Modbus Interface

Terminal 37 PB, Terminal 38 PA

To connect several instruments by means of a network or to configure a PROFIBUS DP connection, consult the PROFIBUS manual. Use appropriate network cable.

**Note:** The switch must be ON, if only one instrument is installed, or on the last instrument in the bus.




Profibus, Modbus Interface PCB (RS 485)

**A** On - OFF switch

### 3.9.3 HART Interface

Terminals 38 (+) and 37 (-).

The HART interface PCB allows for communication via the HART protocol. For detailed information, consult the HART manual.





HART Interface PCB

### 3.9.4 USB Interface

The USB Interface is used to store Logger data and for Firmware upload. For detailed information see the corresponding installation instruction.

The optional third signal output 0/4 – 20 mA PCB [B] can be plugged onto the USB interface and used in parallel.



USB Interface

**A** USB interface PCB

**B** Third signal output 0/4 - 20 mA PCB



## 4. Instrument Setup

After installation according to checklist proceed as following:


### 4.1. Prepare Reagents

- 1 Prepare reagents. See [Refill or replace Reagents, p. 43](#).
- 2 Insert the suction lances into the canisters.

### 4.2. Peristaltic Pump

The instrument is delivered with opened occlusion frames.

- 1 Activate the peristaltic pump tubes by closing the occlusion frame [B].



### 4.3. Establish Sample Flow




#### WARNING

##### Water pollution

The drain of the photometer outlet contains DPD.

- ♦ At no means recirculate it into the water system.




- 1 Open the flow regulating valve [E] and wait until the flow cell is completely filled.
- 2 Adjust overflow tube to the marked level.
- 3 Switch on power.
- 4 Adjust the sample flow so that always a small part of the sample drains off through the overflow tube.
- 5 Start <Fill system>, see [Fill or Flush Reagent System](#), p. 35.


## 4.4. Fill or Flush Reagent System

Fill or flush the reagent tubing:


- upon the initial instrument setup,
- after refilling the reagent canisters,
- before a system shut-down to flush the system with demineralized water until no more reagent is left in the system.



Navigate to menu < Maintenance / Service/Fill system >.  
Press [Enter].



The peristaltic pump is activated for 1.5 minutes.



Press [Exit] 4 x to go back to the operating mode.

- 1 Check tubing and flow cell for leaks and repair if necessary.
- 2 Let the instrument run continuously for 1 hour.

## 4.5. Programming

### Programming

Program all parameters for external devices (interface, recorders, etc.).

Program all parameters for instrument operation (disinfectant, limits, alarms).

Program the reference values of the Verikit in menu <Operation/ Sensors/Verification kits>.

See [Program List and Explanations](#), p. 69.

## **4.6. Calibration**

See [Process Calibration of DIS, p. 50](#)

### **Process DIS**

A process calibration is only possible with a process value higher than 10 ppb ozone. Please note that due to the low stability of the ozone, a process calibration with an elevated concentration is preferred.

Use CHEMATEST (or equivalent photometer) to determine the sample disinfectant concentration. Take the sample directly from the flow cell. Determine the sample disinfectant value by 3 manual DPD measurements. Calculate the average value. Compare this value to the value indicated by the AMI.

Keep in mind the accuracy of your manual measurement. Only correct the instrument if the difference is significant.


Perform process DIS if necessary. See chapter [Calibration, p. 50](#) for details.

## **4.7. Commissioning**

For pharmaceutical applications please follow the IQ/OQ/PQ procedures in the optional validation package.


## 5. Operation

### 5.1. Keys






- A** to exit a menu or command (rejecting any changes) to move back to the previous menu level
- B** to move DOWN in a menu list and to decrease digits
- C** to move UP in a menu list and to increase digits
- D** to open a selected sub-menu to accept an entry

#### Program Access, Exit













## 5.2. Display



- A** RUN normal operation  
 HOLD input closed or cal delay: Instrument on hold (shows status of signal outputs).  
 OFF input closed: control/limit is interrupted (shows status of signal outputs).
- B** ERROR  Error  Fatal Error
- C** Reagent low, indicates remaining reagents in% (17% = 340 ml)
- D** Keys locked, transmitter control via Profibus
- E** Time
- F** Process value with time stamp
- G** Sample flow in B/s
- H** Relay status

### Relay status, symbols

-   upper/lower limit not yet reached  
  upper/lower limit reached  
 control upw./downw. no action  
 control upw./downw. active, dark bar indicates control intensity  
 motor valve closed  
 motor valve: open, dark bar indicates approx. position  
 timer  
 timer: timing active (hand rotating)

### 5.3. Software Structure

<b>Main Menu</b>	1
Messages	▶
Diagnostics	▶
Maintenance	▶
Operation	▶
Installation	▶

<b>Messages</b>	1.1
Pending Errors	▶
Message List	▶

#### Menu **Messages 1**

Reveals pending errors as well as an event history (time and state of events that have occurred at an earlier point of time).  
It contains user relevant data.

<b>Diagnostics</b>	2.1
Identification	▶
Sensors	▶
Sample	▶
I/O State	▶
Interface	▶

#### Menu **Diagnostics 2**

Provides user relevant instrument and sample data.

<b>Maintenance</b>	3.1
Calibration	▶
Process Cal.	▶
Simulation	▶
Set Time	23.09.06 16:30:00

#### Menu **Maintenance 3**

For instrument calibration, relay and signal output simulation, and to set the instrument time.  
It is used by the service personnel.

<b>Operation</b>	4.1
Sensors	▶
Relay Contacts	▶
Logger	▶

#### Menu **Operation 4**

User relevant parameters that might need to be modified during daily routine. Normally password protected and used by the process-operator.  
Subset of menu 5 - Installation, but process-related.

<b>Installation</b>	5.1
Sensors	▶
Signal Outputs	▶
Relay Contacts	▶
Miscellaneous	▶
Interface	▶

#### Menu **Installation 5**

For initial instrument set up by SWAN authorized person, to set all instrument parameters. Can be protected by means of password.

## 5.4. Changing Parameters and values

### Changing parameters

The following example shows how to change the logger interval:

Logger 4.4.1  
Log interval 30 min  
Clear logger no

1 Select the parameter you want to change.

2 Press [Enter]

Logger 4.1.3  
Log interval Interval.  
Clear logger 5 min  
10 min  
30 min  
1 Hour

3 Press [] or [] key to highlight the required parameter.

4 Press [Enter] to confirm the selection or [Exit] to keep the previous parameter).

Logger 4.1.3  
Log interval 10 min  
Clear logger no

⇒ The selected parameter is highlighted but not saved yet.

5 Press [Exit].

Logger 4.1.3  
Log interval Save ?  
Clear logger Yes  
no

⇒ Yes is highlighted.

6 Press [Enter] to save the new parameter.

⇒ The system reboots, the new parameter is set.

### Changing values

Alarm DIS 5.3.1.1.1  
Alarm High 500.0 ppb  
Alarm Low 6.0 ppb  
Hysteresis 1.0 ppb  
Delay 5 Sec

1 Select the value you want to change.

2 Press [Enter].

3 Set required value with [] or [] key.

Alarm DIS 5.3.1.1.1  
Alarm High 300.0 ppb  
Alarm Low 6.0 ppb  
Hysteresis 1.0 ppb  
Delay 5 Sec

4 Press [Enter] to confirm the new value.

5 Press [Exit].

⇒ Yes is highlighted.

6 Press [Enter] to save the new value.



## 6. Maintenance

### 6.1. Maintenance Schedule

<b>Every 2–4 weeks</b>	Clean reagent canisters and prepare new reagents.
<b>Every 6 months</b>	Recommendation: Check photometer with verification kit <a href="#">Verification, p. 46</a> .
<b>Yearly</b>	Exchange reagent pump tubes, see <a href="#">Tube Replacement, p. 54</a> .
<b>By occurrence</b>	<p>E010, Sample flow low: Check sample flow (see also <a href="#">Troubleshooting, p. 57</a>)</p> <p>E020, FOME dirty: <a href="#">Cleaning the Photometer, p. 51</a></p> <p>E022, Reagent empty: <a href="#">Refill or replace Reagents, p. 43</a></p> <p>E065, Reagents low: <a href="#">Refill or replace Reagents, p. 43</a></p> <p>E066, Reagents expired, <a href="#">Refill or replace Reagents, p. 43</a></p>

## **6.2. Stop of Operation for Maintenance**

- 1** Put the suction lances into a bucket with demineralized water.
- 2** Start <Fill system>.  
⇒ *The reagent tubes are flushed with water.*
- 3** Remove the suction lances from the water.
- 4** Start <Fill system> again.  
⇒ *The water will be pumped out of the reagent tubes.*
- 5** Stop sample flow.
- 6** Wait until level in flow cell is empty.
- 7** Shut off power of the instrument.

### 6.3. Refill or replace Reagents

The liquid level in canister 2 is monitored. The following messages are displayed:

Canister almost empty	Maintenance E065 - Reagents low and the remaining reagent volume in % (starting at 17 % = 340 ml).
Canister empty	Error E022 - Reagent empty

**Note:** Before refilling the reagents, rinse the canisters with demineralized water.


#### CAUTION

##### Chemical exposure hazard

- ♦ Observe the necessary security measures when manipulating dangerous chemicals.
- ♦ Read the Material Safety Data Sheets carefully!



#### Canister set up



### Reagent consumption

The 2 liter reagent canister will last for at least 33 days of operation with the default measurement interval of 6 minutes. The provided reagent set (for 3 canisters) therefore lasts for at least 3 months of operation.

**Note:** To achieve a reagent blank of less than 5 ppb, the canisters must be consumed within 30 days.

Measuring interval	Duration per canister
5 minutes	28–40 days
6 minutes	33–47 days
8 minutes	44–63 days
10 minutes	55–79 days

### Contents of the reagent set

A-85.410.210 Reagent set for the measurement of ozone:

- ♦ Oxycon On-Line DPD (3 bottles)
- ♦ Oxycon On-Line Buffer O3 (3 bags)

Personal protective equipment:



*Oxycon On-Line DPD:*

*H314: Causes severe skin burns and eye damage.*

*H318: Causes serious eye damage.*




*Oxycon On-Line Buffer O3:*

*H373: May cause damage to organs through prolonged or repeated exposure.*



### 6.3.1 Reagents for measuring Ozone

**Prepare  
Oxycon  
On-line DPD**

- 1 Rinse the canister [E] labelled OXYCON ON LINE DPD Reagent with demineralized water.
- 2 Fill the canister up to the 2 liter mark with demineralized water.
- 3 Slowly pour the content of a bottle of concentrate Oxycon On-line DPD into the canister.  
 *Avoid splashing!*
- 4 Close the canister with the screw cover and tighten it well.
- 5 Mix the demineralized water and the reagents well.
- 6 Put the canister [E] into the holder [G].
- 7 Remove the screw cover, insert the suction lance [A] and tighten the screw cover.

**Prepare  
Oxycon  
On-line Buffer  
O3**


- 1 Rinse the canister [F] labelled OXYCON ON LINE Ozone Reagent with demineralized water.
- 2 Fill the canister up to the 2 liter mark with demineralized water.
- 3 Slowly pour the content of one bag of Oxycon On-line Buffer O3 into the canister.
- 4 Close the canister with the screw cover and tighten it well.
- 5 Mix the demineralized water and the reagents well.
- 6 Put the canister [F] into the holder [G].
- 7 Remove the screw cover, insert the suction lance [B] and tighten the screw cover.

**Start-up**

- 1 Fill reagent system. See [Fill or Flush Reagent System, p. 35](#).
- 2 Reset the reagent expiry counter in menu 3.2.3.3  
<Maintenance>\<Service>\<Reagents>\<Change reagents>\<yes>.

## 6.4. Verification

The verification kit contains two optical filters (labeled “low” and “high”) with certified reference absorptions of approximately 0.09 A and 0.18 A, which corresponds to approximately 250 ppb and 500 ppb of ozone. The exact values are specified in the enclosed calibration certificate. The absorption of the filters were chosen to lie in the center and at the upper limit of the measurement range of the AMI Codes-II O3.



**A** Storage box  
**B** Verification filters

**C** Cleaning wipes for optical surfaces

The verification procedure confirms the photometric accuracy and linearity of the core components of AMI Codes-II O3, i.e. photometer and converter electronics, over the entire measurement range by comparison of the absorbances measured by the AMI Codes-II O3 with the certified reference values. A maximum deviation of  $\pm 0.010A$  is required for a successful photometer verification.

### Reference values

Prior to performing the first verification and after each recertification, the reference values for the filters "low" and "high" need to be set in menu 4.1.1 <Operation>\<Sensors>\<Verification kits>. The reference values are specified in the enclosed calibration certificate.

### Verification procedure


Before each use, check the expiration date on the calibration certificate. If the expiration date has expired, send the verification kit to Swan for recertification.

Carefully inspect both verification filters for visible contaminations (dust or stains) as these can prevent a successful verification. If necessary, apply the cleaning procedure described in [Cleaning, p. 48](#).

To start the verification, follow the dialog in menu 3.2.1 <Maintenance> / <Service> / <Verification>.

**Note:** Start any time, if a measuring cycle is in progress wait for next prompt.

- 1 Select the verification filter "low". Press [Enter] to continue.
- 2 Stop sample flow by closing the regulating valve. Wait for next prompt.  
⇒ *The constant head is drained and an automatic zero measurement is performed.*
- 3 Rinse the verification filter "low" with deionized water to remove any dust particles.
- 4 Open the photometer and insert the verification filter "low". Press [Enter] to continue.



- 5 Align the triangle shape either to the front or backside and adjust for minimal absorbance (see AMI Display).
- 6 Press [Enter] to save the verification measurement.
- 7 Remove the verification filter “low” from the photometer and shake off large water droplets. Let the filter dry before putting it back into the storage box.
- 8 Close the photometer with the screw plug. Press [Enter]  
⇒ *A final zero measurement is performed and the results are saved.*
- 9 The results of the verification are displayed. Press [Exit].
- 10 Repeat steps 1–9 with the verification filter “high”.

If the verification ends with an error message, see [Troubleshooting, p. 57](#).

### Verification history

Can be reviewed in menu 2.2.1.5 <Diagnostics>/<Sensors>/<Photometer>/<Ver. History>.

### Cleaning

Use the provided wipes or other lint-free, non-abrasive optical grade wipes. If you choose dry wipes, use analytical grade isopropanol or ethanol to moisturize the wipes before application. Do not use any other cleaning agents or wipes, as they can damage the optical surfaces.

Wear powder-free laboratory gloves during cleaning to keep grease/salt from your skin away from the verification filters.

- 1 Prior to mechanical cleaning, rinse the verification filters with de-ionized water or blow off loose dust/particles. Shake off excess water.
- 2 If particles or stains remain on the filter after step 1, carefully wipe the optical surfaces. Allow residues of the cleaning agent to evaporate.
- 3 Check the optical surfaces. Repeat the cleaning procedure if there is any residual dirt.



#### **Storage and handling**

Observe the following points when handling the verification filters:

- ♦ When not in use, the verification filters should always be kept in the provided box.
- ♦ Avoid soiling of the optical surfaces as far as possible.
- ♦ The optical surfaces must not come into contact with hard objects as these can scratch the optical surfaces.
- ♦ Dirt or scratches on the optical surfaces change the optical properties of the verification filters and may make recertification or even replacement of the verification filters necessary.

#### **Recertification**

The calibration certificate is valid for two years from the date of issue. Please contact your local SWAN dealer if recertification or inspection of your verification filters is required. When returned for recertification, the verification filters are measured as received before cleaning and recertification. The data of this measurement are available on request.

## 6.5. Calibration

### Process Calibration of DIS

**Note:** Perform process calibration only if:

- the sample concentration is close to the desired process value (stable value)
- you are sure that the reagents are mixed completely and correctly
- if the difference to the manual measurement is significant
- keep in mind the accuracy of your manual measurement

A process calibration is only possible with a process value higher than 10 ppb ozone. Please note that due to the low stability of the ozone, a process calibration with an elevated concentration is preferred.

Use CHEMATEST (or equivalent photometer) to determine the sample disinfectant concentration. Determine the sample disinfectant value by 3 manual DPD measurements. Calculate the average value. Compare this value to the value indicated by the AMI.

Enter process value (0.050 mg/l = 50 ppb) under menu [3.1.1, p. 71](#) for Process DIS

Possible error message see [Error List, p. 59](#).

**Zero** A zero is automatically done before each measurement.


## 6.6. Cleaning the Photometer

Clean the photometer after indication by alarm (E020, FOME dirty). Switch off the instrument according to instructions in [Stop of Operation for Maintenance](#), p. 42.


### Material

Small brush.

### Procedure



- 1 Close the flow regulating valve [A].
- 2 Wait until the sample flow through the photometer has stopped.
- 3 Unscrew the screw plug [B] from the photometer [C].



- 4 Clean the Photometer with a small brush [D].
- 5 Screw the plug to the photometer.
- 6 Open the flow regulating valve.

## 6.7. Cleaning the Flow Cell



### CAUTION


**Acrylic glass parts are fragile and scratch-sensitive.**

Possible damage of acrylic glass parts due to scrubbing materials.

- ♦ Never use organic solvents or scrubbing materials to clean acrylic glass parts.
- ♦ Use soft detergent and rinse well. Eliminate lime deposits with a common household deliming agent in standard concentration.
- ♦ Do not drop the constant head tube


### 6.7.1 Disassemble the Flow Cell

The flow cell can be easily disassembled. Before starting, switch off the instrument according to the instructions in [Stop of Operation for Maintenance](#), p. 42.



- Cleaning**
- 1 Switch off the instrument according to instructions in [Stop of Operation for Maintenance, p. 42](#)
  - 2 Remove the constant head cover [A].
  - 3 Remove the constant head tube [C] from the flow cell block.
  - 4 Pull the overflow tube [B] out of the flow cell block [D].
  - 5 Clean all acrylic parts with a soft brush (bottle cleaner) and soapy water.
  - 6 Rinse well with demineralized water.

### 6.7.2 Assemble the Flow Cell



- 1 Replace the gasket [D] before reassembling the flow cell.  
**Note:** A film of teflon paste (e.g. Fomblin from Solvay Solexis) on the gaskets improves tightness and life time.
- 2 Push the overflow tube [B] through the flow cell block as far as it reaches the drain.
- 3 Install the constant head tube [C] onto the flow cell block.
- 4 Put the cover onto the constant head tube.
- 5 Align the overflow tube with the upper level mark.

## 6.8. Tube Replacement

### 6.8.1 Replace the Pump Tubes

The pump tube [D] of the peristaltic pump is exposed to a minimal wear. It is therefore recommended to exchange the pump tube annually.




#### CAUTION

##### Pollution of reagents possible.

If the occlusion frames are opened during operation, already mixed reagents will flow back into the reagent canisters and pollute the reagents.

- ♦ Never open the occlusion frames if the instrument is in operation.
- ♦ Proceed according to [Stop of Operation for Maintenance, p. 42](#) before opening the occlusion frames.

#### Overview



**A** Pump housing

**B** Occlusion frame closed

**C** Rotor

**D** Pump tube


**E** Pump inlet

**F** Pump outlet

**G** Protection cap

### Dismount pump tubes

The pump tube can easily be dismantled and mounted. Proceed as follows:



- A** Pump housing
- B** Occlusion frame open
- C** Rotor
- D** Pump tube
- E** Pump inlet
- F** Pump outlet

- 1 Switch off the instrument according to instructions in [Stop of Operation for Maintenance, p. 42](#).
- 2 Remove the protection cap.
- 3 Open the occlusion frames [B] by turning them counter-clockwise.
- 4 Remove the pump tubes [D] from the rotor [C] by pulling the complete occlusion frames [B] out of the holder.
- 5 Disconnect the reagent tubes from the old pump tubes and connect them to the new pump tubes.
- 6 Install the new pump tubes by pushing the occlusion frames onto the holder.
- 7 Lock the occlusion frames. Check that the occlusion frames and the tubes are aligned perpendicular to the axis of the rotor.
- 8 Insert the suction lances into the corresponding containers.
- 9 Start the <Fill system> function.

## 6.9. Longer Stop of Operation

- 1 Put the suction lances into a bucket with demineralized water.
- 2 Start <Fill system>.  
⇒ *The reagent tubes are flushed with water.*
- 3 Remove the suction lance from the water.
- 4 Start <Fill system> again.  
⇒ *The water will be pumped out of the reagent tubes.*
- 5 Stop sample flow.
- 6 Wait until flow cell is empty.
- 7 Shut off power of the instrument.
- 8 Open the occlusion frames of the peristaltic pump, see [Replace the Pump Tubes](#), p. 54.



## 7. Troubleshooting

This chapter provides some hints to make troubleshooting easier. For any detailed information on how to handle or clean parts please see [Maintenance, p. 41](#). For any detailed information how to program the instrument please see [Program List and Explanations, p. 69](#).

### 7.1. General Instructions

**Note:** The sample for the manual measurement (with DPD) must be taken directly from the flow cell.

If you need further help please contact your dealer. Note serial number of instrument and all diagnostic values before doing so.

**Diagnostic values**      Zero photometry: 10'000–16'000 Hz (mostly near 16 000 Hz)  
Slope photometry: 0.5–2.0

**Frequently asked questions**

**Problem**

**Unstable values**

**Codes display higher or lower than manual measurement**

**Sample flow alarm, but there is sample**

**Possible Reasons**

- ◆ Sample taken too close to feeding line.
- ◆ Sample flow too irregular or too low.
- ◆ Wrong manual measurement or old chemicals have been used. Repeat the verification.
- ◆ Reagents of AMI Codes mixed wrongly or not completely.
- ◆ Reagents older than 30 days (E066).
- ◆ Check sample flow at photometer outlet. It must be at least 100 ml/min. For that place the photometer outlet tube into a measuring cup for 1 minute.
- ◆ Check sample line for pressure fluctuation.
- ◆ Check for regular air bubble pattern.
- ◆ Check flow alarm values in menu [5.3.1.3, p. 77](#)).

## 7.2. Calibration Errors

### 7.2.1 Process Calibration DIS

**Possible error message**

Slope error:

Possible cause	Corrective Action
Wrong manual measurement.	Repeat the manual measurement. Use fresh reagents.
<ul style="list-style-type: none"> <li>♦ Wrong reagent mixture</li> <li>♦ Reagents not completely solved in water.</li> <li>♦ Reagents older than 30 days.</li> </ul>	<ul style="list-style-type: none"> <li>♦ Make a correct mixture.</li> <li>♦ Mix long and intensively.</li> </ul>

## 7.3. Verification Errors

**Possible error message**

Invalid zero measurement:

Possible cause	Corrective Action
Gas bubble in the photometer.	Rinse the photometer with sample for 1-2 minutes and repeat the verification.

Verification error

Possible cause	Corrective Action
Deviation between measured value and reference value is too high	<ul style="list-style-type: none"> <li>♦ Clean the verification filters according to <a href="#">Cleaning, p. 48</a> and repeat the verification.</li> <li>♦ If filter cleaning does not result in a successful verification, clean and rinse the photometer according to <a href="#">Cleaning the Photometer, p. 51</a> and repeat the verification.</li> <li>♦ If the problem persists, call service.</li> </ul>

## 7.4. Error List

### Error

Non-fatal Error. Indicates an alarm if a programmed value is exceeded.

Such Errors are marked **E0xx** (bold and black).


### Fatal Error

Control of dosing devices is interrupted.

The indicated measured values are possibly incorrect.

Fatal Errors are divided in the following two categories:

- Errors which disappear if correct measuring conditions are recovered (i.e. Sample Flow low).  
Such Errors are marked **E0xx** (bold and orange)
- Errors which indicate a hardware failure of the instrument.  
Such Errors are marked **E0xx** (bold and red)



### Error or fatal Error


Error not yet acknowledged.

Check **Pending Errors 1.1.5** and take corrective action.




### Reagent level low

Indicates the remaining reagent in percent.



Navigate to menu <Messages>/<Pending Errors>.



Press [ENTER] to acknowledge the Pending Errors.

⇒ *The Error is reset and saved in the Message List.*

Error	Description	Corrective action
<b>E001</b>	DIS. Alarm high	<ul style="list-style-type: none"> <li>– check process</li> <li>– check programmed value in menu <a href="#">5.3.1.1.1, p. 77</a></li> </ul>
<b>E002</b>	DIS. Alarm Low	<ul style="list-style-type: none"> <li>– check process</li> <li>– check programmed value in menu <a href="#">5.3.1.1.25, p. 77</a></li> </ul>
<b>E005</b>	DIS. too high	<ul style="list-style-type: none"> <li>– check process</li> </ul>
<b>E009</b>	Sample Flow high	<ul style="list-style-type: none"> <li>– check sample input pressure</li> <li>– readjust sample flow</li> <li>– check programmed value in menu <a href="#">5.3.1.3.x, p. 77</a></li> </ul>
<b>E010</b>	Sample Flow low	<ul style="list-style-type: none"> <li>– check sample input pressure</li> <li>– readjust sample flow</li> <li>– clean instrument, see <a href="#">Cleaning the Photometer, p. 51</a></li> <li>– check programmed value in menu <a href="#">5.3.1.3.x, p. 77</a></li> </ul>
<b>E013</b>	Case Temp. high	<ul style="list-style-type: none"> <li>– check case/environment temperature</li> <li>– check programmed value in menu <a href="#">5.3.1.5, p. 77</a></li> </ul>
<b>E014</b>	Case Temp. low	<ul style="list-style-type: none"> <li>– check case/environment temperature</li> <li>– check programmed value in menu <a href="#">5.3.1.6, p. 77</a></li> </ul>
<b>E017</b>	Control Timeout	<ul style="list-style-type: none"> <li>– check control device or programming in Installation, Relay contact, Relay 1/2 <a href="#">5.3.2 and 5.3.3, p. 77</a></li> </ul>
<b>E018</b>	Reagent Pump	<ul style="list-style-type: none"> <li>– shut off power</li> <li>– check wiring, see <a href="#">Connection Diagram, p. 24</a></li> </ul>
<b>E019</b>	Photometer not connected	<ul style="list-style-type: none"> <li>– shut off power</li> <li>– check wiring of photometer, see <a href="#">Connection Diagram, p. 24</a></li> </ul>
<b>E020</b>	Photometer dirty	<ul style="list-style-type: none"> <li>– check process,</li> <li>– clean photometer, see <a href="#">Cleaning the Photometer, p. 51</a></li> </ul>

Error	Description	Corrective action
<b>E021</b>	DIS. invalid	– This error appears after start-up and will disappear after the first valid measurement is finished.
<b>E022</b>	Reagent empty	– refill reagents, see <a href="#">Refill or replace Reagents</a> , p. 43
<b>E024</b>	Input active	– No action necessary. – This message is displayed if “Fault = Yes” is programmed, see <a href="#">5.3.4</a> , p. 81.
<b>E026</b>	IC LM75	– call service
<b>E028</b>	Signal output open	– check wiring on signal outputs 1 and 2
<b>E030</b>	EEprom Frontend	– call service
<b>E031</b>	Calibration Recout	– call service
<b>E032</b>	Wrong Frontend	– call service
<b>E033</b>	Power-on	– none, normal status
<b>E034</b>	Power-down	– none, normal status
<b>E065</b>	DPD / Buffer	– Operating display, upper status line. The number next to the triangle, indicates the remaining reagents in%. Refill reagents on time. See <a href="#">Refill or replace Reagents</a> , p. 43
<b>E066</b>	Reagents expired	– Canister filling is older than 30 days. – This message is displayed if “Reag. expiry warning = Yes” is programmed, see <a href="#">5.1.2</a> , p. 73.

## 7.5. Replacing Fuses



### WARNING


#### External Voltage.

External supplied devices connected to relay 1 or 2 or to the alarm relay can cause electrical shocks.

- ♦ Make sure that the devices connected to the following contacts are disconnected from the power before resuming installation.
  - relay 1
  - relay 2
  - alarm relay

When a fuse has blown, find out the cause and fix it before replacing it with a new one.

Use tweezers or needle-nosed pliers to remove the defective fuse. Use original fuses provided by SWAN only.



- A** AC variant: 1.6 AT/250 V Instrument power supply  
DC variant: 3.15 AT/250 V Instrument power supply
- B** 1.0 AT/250V Relay 1
- C** 1.0 AT/250V Relay 2
- D** 1.0 AT/250V Alarm relay
- E** 1.0 AF/125V Signal output 2
- F** 1.0 AF/125V Signal output 1
- G** 1.0 AF/125V Signal output 3

## 8. Program Overview

All menus are password-protected as soon as an administrator password has been defined.

- ♦ Menu 1 **Messages** informs about pending errors and maintenance tasks and shows the error history. Access by administrator, service and operator. No settings can be modified.
- ♦ Menu 2 **Diagnostics**: Access by administrator, service and operator. No settings can be modified.
- ♦ Menu 3 **Maintenance**: Calibration, simulation of outputs and set time/date. Access by administrator and service.
- ♦ Menu 4 **Operation**: Allows to set limits, alarms values, etc. Access by administrator and service.
- ♦ Menu 5 **Installation**: Defining assignment of all inputs and outputs, measuring parameters, interface, passwords, etc. Access by administrator only.

Further information see chapter 9, [5.4.4, p. 83](#).

### 8.1. Messages (Main Menu 1)

Pending Errors 1.1*	Pending Errors	1.1.5*
Maintenance List 1.2*	Maintenance List	1.2.5*
Message List 1.3*	Number Date, Time	1.3.1*
Audit Trail 1.4*	Number Date, Time Event Note	

\* Menu numbers

8.2. Diagnostics (Main Menu 2)

<b>Identification</b>	<i>Designation</i>	<i>AMI Codes-II O3</i>	* Menu numbers
2.1*	<i>Version</i>	<i>V6.21 - 01/18</i>	
	<b>Peripherals</b>	<i>PeriClip 1 / 1.05</i>	2.1.3.1*
	2.1.3*		
	<b>Factory Test</b>	<i>Instrument</i>	2.1.4.1*
	2.1.4*	<i>Motherboard</i>	
	<b>Operating Time</b>	<i>Years / Days / Hours / Minutes / Seconds</i>	2.1.5.1*
	2.1.5*		
<b>Sensors</b>	<b>Photometer</b>	<i>Current Value</i>	
2.2*	2.2.1*	<i>(Raw value)</i>	
		<i>Absorbance</i>	
		<b>Cal. History</b>	<i>Number</i> 2.2.1.4.1*
		2.2.1.4*	<i>Date, Time</i>
			<i>Slope</i>
		<b>Ver. History</b>	<i>Number</i> 2.2.1.5.1*
		2.2.1.5*	<i>Date, Time</i>
			<i>Absorbance</i>
			<i>Reference value</i>
			<i>Deviation</i>
	<b>Miscellaneous</b>	<i>Case Temp.</i>	2.2.3.1*
	2.2.3*		
<b>Sample</b>	<i>Sample ID</i>	2.3.1*	
2.3*	<i>Sample Flow / (Raw value)</i>		
<b>I/O State</b>	<i>Alarm Relay</i>	2.4.1*	
2.4*	<i>Relay 1/2</i>	2.4.2*	
	<i>Input</i>		
	<i>Signal Output 1/2</i>		
<b>Interface</b>	<i>Protocol</i>	2.5.1*	(only with RS485
2.5*	<i>Device Address</i>	2.5.2.1*	interface)
	<i>Baud Rate</i>	2.5.3.1*	
	<i>Parity</i>	2.5.4.1*	



8.3. Maintenance (Main Menu 3)

<b>Calibration</b>	<b>Process DIS</b>	<i>Current Value</i>	* Menu numbers
3.1*	3.1.1*	<i>Slope</i>	
		<i>Process Value</i>	3.1.1.4*
<b>Service</b>	<b>Verification</b>	<i>(Progress)</i>	3.2.1.1*
3.2*	3.2.1*		
	<b>Fill System</b>	<i>(Progress)</i>	3.2.2.5*
	3.2.2*		
	<b>Reagents</b>	<i>Last change</i>	
	3.2.3*	<i>Remaining days</i>	
		<i>Change reagents</i>	3.2.3.3*
<b>Simulation</b>	<i>Alarm Relay</i>	3.3.1*	
3.3*	<i>Relay 1</i>	3.3.2*	
	<i>Relay 2</i>	3.3.3*	
	<i>Signal Output 1</i>	3.3.4*	
	<i>Signal Output 2</i>	3.3.5*	
<b>Set Time</b>	<i>(Date), (Time)</i>		
3.4*			

8.4. Operation (Main Menu 4)

<b>Sensors</b>	<b>Verification kits</b>	Verikit low	4.1.1.1*	* Menu numbers
4.1*	4.1.1*	Verikit high	4.1.1.2*	
	<i>Filter Time Const.</i>	4.1.2*		
	<i>Hold after Cal.</i>	4.1.3*		
	<i>Meas. Interval</i>	4.1.4*		
<b>Relay Contacts</b>	<b>Alarm Relay</b>	<b>Alarm DIS</b>	<i>Alarm High</i>	4.2.1.1.1*
4.2*	4.2.1*	4.2.1.1*	<i>Alarm Low</i>	4.2.1.1.26*
			<i>Hysteresis</i>	4.2.1.1.36*
			<i>Delay</i>	4.2.1.1.46*
	<b>Relay 1 &amp; 2</b>	<i>Setpoint</i>	4.2.x.x*	
	4.2.2* & 4.2.3*	<i>Hysteresis</i>	4.2.x.x*	
		<i>Delay</i>	4.2.x.x*	
	<b>Input</b>	<i>Active</i>	4.2.4.1*	
	4.2.4*	<i>Signal Outputs</i>	4.2.4.2*	
		<i>Output / Control</i>	4.2.4.3*	
		<i>Fault</i>	4.2.4.4*	
		<i>Delay</i>	4.2.4.5*	
<b>Logger</b>	<i>Log Interval</i>	4.3.1*		
4.3*	<i>Clear Logger</i>	4.3.2*		

8.5. Installation (Main Menu 5)

Sensors	Disinf.	5.1.1*		* Menu numbers
5.1*	Reag. expiry warning	5.1.2*		
Signal Outputs	Signal Output 1&2	Parameter	5.2.1.1 & 5.2.2.1*	
5.2*	5.2.1* & 5.2.2*	Current Loop	5.2.1.2 & 5.2.2.2*	
		Function	5.2.1.3 & 5.2.2.3*	
		Scaling	Range Low	5.2.x.40.x*
		5.2.x.40	Range High	5.2.x.40.x*
Relay Contacts	Alarm Relay	Alarm DIS	Alarm High	5.3.1.1.1*
5.3*	5.3.1*	5.3.1.1*	Alarm Low	5.3.1.1.x*
			Hysteresis	5.3.1.1.x*
			Delay	5.3.1.1.x*
		Sample Flow	Flow Alarm	5.3.1.3.1*
		5.3.1.3*	Alarm High	5.3.1.3.x*
			Alarm Low	5.3.1.3.x*
		Case Temp. high	5.3.1.5*	
		Case Temp. low	5.3.1.6*	
	Relay 1&2	Function	5.3.2.1 & 5.3.3.1*	
	5.3.2* & 5.3.3*	Parameter	5.3.2.x & 5.3.3.x*	
		Setpoint	5.3.2.x & 5.3.3.x*	
		Hysteresis	5.3.2.x & 5.3.3.x*	
		Delay	5.3.2.x & 5.3.3.x*	
	Input	Active	5.3.4.1*	
	5.3.4*	Signal Outputs	5.3.4.2*	
		Output/Control	5.3.4.3*	
		Fault	5.3.4.4*	
		Delay	5.3.4.5*	

Miscellaneous 5.4*	Language	5.4.1*	* Menu numbers
	Set defaults	5.4.2*	
	Load Firmware	5.4.3*	
	Access	Administrator	
	5.4.4*	5.4.4.1*	
		Name	
		Function	
		Password	
		User 1–4	
		5.4.4.x*	
Interface 5.5*			(only with RS485 interface)
	Sample ID	5.4.5*	
	Line Break Detection	5.4.6*	
	Protocol	5.5.1*	
	Device Address	5.5.21*	
	Baud Rate	5.5.31*	
	Parity	5.5.41*	

## 9. Program List and Explanations

### 1 Messages

#### 1.1 Pending Errors

- 1.1.5 Provides the list of active errors with their status (active, acknowledged). If an active error is acknowledged, the alarm relay is active again. Cleared errors are moved to the Message list.

#### 1.2 Maintenance List

- 1.2.5 Indicates necessary maintenance, e.g. preparing new reagents.

#### 1.3 Message List

- 1.3.1 Shows the error history: Error code, date and time of issue and status (active, acknowledged, cleared). 65 errors are memorized. Then the oldest error is cleared to save the newest error (circular buffer).

#### 1.4 Audit Trail

Shows the audit trail: event, menu, date and time of issue. 96 events are memorized. Then the oldest event is cleared to save the newest one (circular buffer).

### 2 Diagnostics

In diagnostics mode, the values can only be viewed, not modified.

#### 2.1 Identification

**Designation:** View the designation of the instrument.

**Version:** Firmware of instrument (e.g. V6.21-01/18)

- 2.1.3 **Peripherals:** PeriClip 1: Firmware of peristaltic pump (e.g. 1.05)

- 2.1.4 **Factory Test:** Test date of the instrument, motherboard and frontend QC factory test.

- 2.1.5 **Operating Time:** Years/days/hours/minutes/seconds

#### 2.2 Sensors

- 2.2.1 **Photometer:**

*Current value:* Shows the actual photometer signal [ppb].

*Raw value:* Shows the actual photometer signal [Hz].

*Absorbance:* Process value, depends on sample.

- 2.2.1.4 **Cal. History:** Shows the diagnostic values of the last calibrations.  
*Number:* Calibration counter.  
*Date, Time:* Date and time of the calibration.  
*Slope:* Slope is a correction factor calculated on the basis of a process calibration.  
 Range: 0.8–1.2
- 2.2.1.5 **Ver. History:** Shows the verification values of the last verifications:  
*Number:* Verification counter.  
*Date, Time:* Date and time of the verification.  
*Absorbance:* Measured absorbance of the reference kit.  
*Reference value:* True value of the reference kit according to label.  
*Deviation:* Deviation between the measured value and the reference value in %.
- 2.2.3 **Miscellaneous:**
- 2.2.3.1 *Case Temp:* Shows the current temperature in [°C] inside the transmitter.

## 2.3 Sample

- 2.3.1 **Sample ID:** Shows the identification assigned to a sample. This identification is defined by the user to identify the location of the sample.
- Sample Flow:** Shows the actual sample flow in B/s (bubbles per second)]. The Sample flow must be above 5 B/s.

## 2.4 I/O State

Shows current status of all in- and outputs.

- 2.4.1/2.4.2
- |                               |   |
|-------------------------------|---|
| <i>Alarm Relay:</i>           | Active or inactive                            |
| <i>Relay 1 and 2:</i>         | Active or inactive                            |
| <i>Input:</i>                 | Open or closed                                |
| <i>Signal Output 1 and 2:</i> | Actual current in mA                          |
| <i>Signal Output 3:</i>       | Actual current in mA (if option is installed) |

## 2.5 Interface

Only available if optional interface is installed.  
 Review programmed communication settings.

## 3 Maintenance

### 3.1 Calibration

- 3.1.1 Process DIS:** Possibility to correct the disinfectant value. See [Process Calibration of DIS, p. 50](#), for more details.

### 3.2 Service

- 3.2.1 Verification:** Performs a verification using the reference kit. Follow dialog. See [Verification, p. 46](#).
- 3.2.2 Fill System:** Activates the reagent pump.
- 3.2.3 Reagents:** Displays the date of the last filling and the remaining number of days until the maximum storage time of 30 days is exceeded.
- 3.2.3.3 Change reagents:** Resets the counter and saves the date of the new filling.



### 3.3 Simulation

To simulate a value or a relay state, select the

- ♦ alarm relay,
- ♦ relay 1 or 2
- ♦ signal output 1 or 2

with the [] or [] key.

Press the [Enter] key.

Change the value or state of the selected item with the [] or [] key.

Press the [Enter] key.

⇒ *The value is simulated by the relay/signal output.*

<i>Alarm Relay:</i>	Active or inactive
<i>Relay 1 and 2:</i>	Active or inactive
<i>Signal Output 1 and 2:</i>	Actual current in mA
<i>Signal Output 3:</i>	Actual current in mA (if option is installed)

At the absence of any key activities, the instrument will switch back to normal mode after 20 min. If you quit the menu, all simulated values will be reset.

### 3.4 Set Time

Adjust date and time.

## 4 Operation

### 4.1 Sensors

#### 4.1.1 Verification kits:

4.1.1.1 *Verikit low*: Set the absorbance value of the verification filter “low” according to the calibration certificate.  
Range: 0.0000–0.1000

4.1.1.2 *Verikit high*: Set the absorbance value of the verification filter “high” according to the calibration certificate.  
Range: 0.1500–0.2000

4.1.2 *Filter Time Constant*: Used to damp noisy signals. The higher the filter time constant, the slower the system reacts to changes of the measured value.  
Range: 5–300 sec

4.1.3 *Hold after Cal*: Delay permitting the instrument to stabilize again after calibration. During calibration- plus hold-time, the signal outputs are frozen (held on last valid value), alarm values, limits are not active.  
Range: 0–6'000 sec

4.1.4 *Meas. Interval*: Measurement interval for disinfectants.  
Range: 5 to 10 min

### 4.2 Relay Contacts

See [5.3 Relay Contacts](#), p. 76

### 4.3 Logger

The instrument is equipped with an internal logger. The data can be copied to a PC with a USB stick if option USB interface is installed. The logger can save approx. 1500 data records. The records consist of: Date, time, alarms, measured value, flow, zero, case temperature.

Range: 1 second to 1 hour

4.3.1 *Log Interval*: Select a convenient log interval. Consult the table below to estimate the max logging time. The logging buffer is designed as circular buffer. If the buffer is full, the oldest data record is erased to make room for the newest one. If the logger interval is set to event driven, a data record of every valid measurement is saved. The interval corresponds with the measuring interval.

Interval	1 s	5 s	1 min	5 min	10 min	30 min	1 h	Event Driven
Time	25 min	2 h	25 h	5 d	10 d	31 d	62 d	

4.3.2 *Clear Logger*: If confirmed with **yes**, the complete logger data is deleted. A new data series is started.



## 5 Installation

### 5.1 Sensors

- 5.1.1 *Disinf*: The measured value can be displayed in two ways:
- ♦ Ozone: the measured value is displayed as ppb O<sub>3</sub>
  - ♦ TC1: the measured value is displayed as ppb Cl<sub>2</sub>
- 5.1.2 *Reag. expiry warning*: If activated, message E066 will be displayed as soon as the reagents are older than 30 days.  
Choose between <Yes> or <No>.

### 5.2 Signal Outputs


- 5.2.1 and 5.2.2 Signal Output 1 and 2:** Assign process value, the current loop range and a function to each signal output.

**Note:** *The navigation in the menu <Signal Output 1> and <Signal Output 2> is equal. For reason of simplicity only the menu numbers of Signal Output 1 are used in the following.*

- 5.2.1.1 *Parameter*: Assign one of the process values to the signal output.  
Available values:
- ♦ DIS
  - ♦ Sample flow
- 5.2.1.2 *Current Loop*: Select the current range of the signal output.  
Make sure the connected device works with the same current range.  
Available ranges: 0–20 mA or 4–20 mA
- 5.2.1.3 *Function*: Define if the signal output is used to transmit a process value or to drive a control unit. Available functions are:
- ♦ Linear, bilinear or logarithmic for process values.  
See [As process values, p. 74](#)
  - ♦ Control upwards or control downwards for controllers.  
See [As control output, p. 75](#)

**As process values**


The process value can be represented in 3 ways: linear, bilinear or logarithmic. See graphs below.



**A** linear

**X** Measured value

**B** bilinear



**X** Measured value (logarithmic)

**5.2.1.40**

**Scaling:** Enter beginning and end point (Range low & high) of the linear or logarithmic scale. In addition, the midpoint for the bilinear scale.

**Parameter DIS:**

5.2.1.40.10 *Range low:* 0.0–500.0 ppb

5.2.1.40.20 *Range high:* 0.0–500.0 ppb

**Parameter Sample flow**

5.2.1.40.13 *Range low:* 0 –600 B/s

5.2.1.40.23 *Range high:* 0 –600 B/s


**As control output**

Signal outputs can be used for driving control units. We distinguish different kinds of controls:

- ♦ *P-controller*: The controller action is proportional to the deviation from the setpoint. The controller is characterized by the P-Band. In the steady-state, the setpoint will never be reached. The deviation is called steady-state error.  
 Parameters: setpoint, P-Band
- ♦ *PI-controller*: The combination of a P-controller with an I-controller will minimize the steady-state error. If the reset time is set to zero, the I-controller is switched off.  
 Parameters: setpoint, P-Band, reset time.
- ♦ *PD-controller*: The combination of a P-controller with a D-controller will minimize the response time to a fast change of the process value. If the derivative time is set to zero, the D-controller is switched off.  
 Parameters: setpoint, P-Band, derivative time.
- ♦ *PID-controller*: The combination of a P-, an I - and a D-controller allows a proper control of the process.  
 Parameters: setpoint, P-Band, reset time, derivative time.

Ziegler-Nichols method for the optimization of a PID controller:

**Parameters:** Setpoint, P-Band, Reset time, Derivative time



**A** Response to maximum control output     $X_p = 1.2/a$   
**B** Tangent on the inflection point         $T_n = 2L$   
**X** Time     $T_v = L/2$

The point of intersection of the tangent with the respective axis will result in the parameters a and L.

Consult the manual of the control unit for connecting and programming details. Choose control upwards or downwards.

### Control upwards/downwards

*Setpoint:* User-defined process value (Measured value or flow)  
*P-Band:* Range below (upwards control) or above (downwards control) the set-point, within the dosing intensity is reduced from 100% to 0% to reach the set-point without overshooting.

**5.2.1.43** Control Parameters: if Parameters = DIS

5.2.1.43.10 *Setpoint:* 0.0–500.0 ppb

5.2.1.43.20 *P-Band:* 0.0–500.0 ppb

**5.2.1.43** Control Parameters: if Parameters = Sample Flow

5.2.1.43.13 *Setpoint:* 0–600 B/s

5.2.1.43.23 *P-Band:* 0 –200 B/s

*Reset time:* The reset time is the time till the step response of a single I-controller will reach the same value as it will be suddenly reached by a P-controller.

Range: 0–9'000 sec

*Derivative time:* The derivative time is the time till the ramp response of a single P-controller will reach the same value as it will be suddenly reached by a D-controller.

Range: 0–9'000 sec

*Control timeout:* If a controller action (dosing intensity) is constantly over 90% during a defined period of time and the process value does not come closer to the setpoint, the dosing process will be stopped for safety reasons.

Range: 0–720 min

## 5.3 Relay Contacts

**5.3.1 Alarm Relay:** The alarm relay is used as cumulative error indicator. Under normal operating conditions the contact is active.

The contact is inactive at:

- ♦ Power loss
- ♦ Detection of system faults like defective sensors or electronic parts
- ♦ High case temperature
- ♦ Lack of reagents
- ♦ Process values out of programmed ranges.

Program alarm levels, hysteresis values and delay times for the following parameters:

- ♦ DIS
- ♦ Sample flow

- 5.3.1.1 Alarm DIS.**
- 5.3.1.1.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay is activated and E001 is displayed in the message list. Range: 0.0–500.0 ppb
- 5.3.1.1.25 *Alarm Low:* If the measured value falls below the alarm low value, the alarm relay is activated and E002 is displayed in the message list.  
Range: 0.0–500.0 ppb
- 5.3.1.1.35 *Hysteresis:* Within the hyst. range, the relay does not switch. This prevents damage of relays contacts when the measured value fluctuates around the alarm value.  
Range: 0.0–500.0 ppb
- 5.3.1.1.45 *Delay:* Duration, the activation of the alarm relay is retarded after the measuring value has risen above/fallen below the programmed alarm.  
Range: 0.00–28'800 sec
- 5.3.1.3 Sample Flow:** Define at which sample flow a flow alarm should be issued.
- 5.3.1.3.1 *Flow Alarm:* Program if the alarm relay should be activated if there is a flow alarm. Choose between yes or no. The flow alarm will always be indicated in the display, pending error list, saved in the message list and the logger.  
Available values: Yes or no
- Note:** Sufficient flow is essential for a correct measurement.  
We recommend to program yes.*
- 5.3.1.3.x *Alarm High:* If the measuring values rises above the programmed value E009 will be issued.  
Range: 100–600 B/s
- 5.3.1.3.x *Alarm Low:* If the measuring values falls below the programmed value E010 will be issued.  
Range: 5–80 B/s
- 5.3.1.5 Case Temp. high:** Set the alarm high value for temperature of electronics housing. If the value rises above the programmed value E013 is issued.  
Range: 30–75 °C
- 5.3.1.6 Case Temp. low:** Set the alarm low value for temperature of electronics housing. If the value falls below the programmed value E014 is issued.  
Range: -10 to +20 °C
- 5.3.2 and 5.3.3 Relay 1 and 2:** The contacts can be set as normally open or normally closed with a jumper. See [Relay 1 and 2, p. 28](#).  
The function of the relay contacts 1 and 2 is defined by the user.

**Note:** The navigation in the menu <Relay 1> and <Relay 2> is equal. For reason of simplicity only the menu numbers of Relay 1 are used in the following.

- 1 First select the functions as:
  - Limit upper/lower
  - Control upwards/downwards
  - Timer
  - Fieldbus
  - End of Batch (relay 2 only)
- 2 Then enter the necessary data depending on the selected function.

5.3.2.1 Function = Limit upper/lower:

When the relays are used as upper or lower limit switches, program the following:

5.3.2.20 *Parameter:* select a process value

5.3.2.300 *Setpoint:* If the measured value rises above respectively falls below the set-point, the relay is activated.

Parameter	Range
DIS	0.0–500.0 ppb
Sample flow	0–600 B/s

5.3.2.400 *Hysteresis:* within the hysteresis range, the relay does not switch. This prevents damage of relay contacts when the measured value fluctuates around the alarm value.

Parameter	Range
DIS	0.0–500.0 ppb
Sample flow	0–200 B/s

5.3.2.50 *Delay:* Duration, the activation of the alarm relay is retarded after the measuring value has risen above/fallen below the programmed alarm.  
Range. 0–600 sec

5.3.2.1 Function = Control upwards/downwards:

The relays may be used to drive control units such as solenoid valves, membrane dosing pumps or motor valves. When driving a motor valve both relays are needed, relay 1 to open and relay 2 to close the valve.

- 5.3.2.22 *Parameter:* Choose on of the following process values.
- ♦ DIS
  - ♦ Sample Flow
- 5.3.2.32 Settings:** Choose the respective actuator:
- ♦ Time proportional
  - ♦ Frequency
  - ♦ Motor valve
- 5.3.2.32.1 **Actuator = Time proportional**
- Examples of metering devices that are driven time proportional are solenoid valves, peristaltic pumps.  
 Dosing is controlled by the operating time.
- 5.3.2.32.20 *Cycle time:* duration of one control cycle (on/off change).  
 Range: 0–600 sec.
- 5.3.2.32.30 *Response time:* Minimal time the metering device needs to react.  
 Range: 0–240 sec.
- 5.3.2.32.4 Control Parameters**  
 Range for each Parameter same as [5.2.1.43, p. 76](#)
- 5.3.2.32.1 **Actuator = Frequency**
- Examples of metering devices that are pulse frequency driven are the classic membrane pumps with a potential free triggering input.  
 Dosing is controlled by the repetition speed of dosing shots.
- 5.3.2.32.21 *Pulse frequency:* Max. pulses per minute the device is able to respond to. Range: 20–300/min.
- 5.3.2.32.31 Control Parameters**  
 Range for each Parameter same as [5.2.1.43, p. 76](#)
- 5.3.2.32.1 **Actuator = Motor valve**
- Dosing is controlled by the position of a motor driven mixing valve.
- 5.3.2.32.22 *Run time:* Time needed to open a completely closed valve  
 Range: 5–300 sec.
- 5.3.2.32.32 *Neutral zone:* Minimal response time in % of the runtime. If the requested dosing output is smaller than the response time, no change will take place.  
 Range: 1–20 %
- 5.3.2.32.4 Control Parameters**  
 Range for each Parameter same as [5.2.1.43, p. 76](#)

### 5.3.2.1 Function = Timer:

The relay will be active repetitively depending on the programmed time scheme.

#### 5.3.2.24 Mode: Operating mode (interval, daily, weekly)

##### 5.3.2.24 Interval

5.3.2.340 *Interval:* The interval can be programmed within a range of 1–1'440 min.

5.3.2.44 *Run Time:* Enter the time the relay stays active.  
Range: 5–32'400 sec.

5.3.2.54 *Delay:* during run time plus the delay time the signal and control outputs are held in the operating mode programmed below.  
Range: 0–6'000 sec.

#### 5.3.2.6 Signal Outputs: Select operating mode of the signal output:

*Cont.:* Signal outputs continue to issue the measured value.

*Hold:* Signal outputs hold the last valid measured value.  
Measurement is interrupted. Errors, except fatal errors, are not issued.

*Off:* Signal outputs are switched off (set to 0 or 4 mA).  
Errors, except fatal errors, are not issued.

#### 5.3.2.7 Output/Control: Select operating mode of the controller output:

*Cont.:* Controller continues normally.

*Hold:* Controller continues based on the last valid value.

*Off:* Controller is switched off.

##### 5.3.2.24 daily

The relay contact can be activated daily, at any time of a day.

5.3.2.341 *Start time:* to set the start time proceed as follows:

- 1 Press [Enter], to set the hours.
- 2 Set the hour with the [▲] or [▼] keys.
- 3 Press [Enter], to set the minutes.
- 4 Set the minutes with the [▲] or [▼] keys.
- 5 Press [Enter], to set the seconds.
- 6 Set the seconds with the [▲] or [▼] keys.

Range: 00:00:00–23:59:59



- 5.3.2.44 *Run Time:* see Interval
- 5.3.2.54 *Delay:* see Interval
- 5.3.2.6 *Signal Outputs:* see Interval
- 5.3.2.7 *Output/Control:* see Interval
- 5.3.2.24 *weekly*

The relay contact can be activated at one or several days, of a week.  
 The daily starting time is valid for all days.

**5.3.2.342 Calendar:**

- 5.3.2.342.1 *Start time:* The programmed start time is valid for each of the programmed days. To set the start time see [5.3.2.341, p. 80](#).  
 Range: 00:00:00–23:59:59

- 5.3.2.342.2 *Monday:* Possible settings, on or off  
 to

- 5.3.2.342.8 *Sunday:* Possible settings, on or off

- 5.3.2.44 *Run Time:* see Interval
- 5.3.2.54 *Delay:* see Interval
- 5.3.2.6 *Signal Outputs:* see Interval
- 5.3.2.7 *Output/Control:* see Interval

- 5.3.2.1 *Function = Fieldbus:*

The relay will be switched via the Profibus input. No further parameters are needed.

- 5.3.3.1 *Function = End of Batch*

This function is only available on relay 2. It is used to communicate with canal switching instruments from third-party suppliers. The relay closes for 1 sec. after each valid measurement. If End of Batch is selected, no further selection is possible.

- 5.3.4 Input:** The functions of the relays and signal outputs can be defined depending on the position of the input contact, i.e. no function, closed or open.

- 5.3.4.1 *Active:* Define when the input should be active:

- No:* Input is never active.
- When closed* Input is active if the input relay is closed
- When open:* Input is active if the input relay is open

- 5.3.4.2 **Signal Outputs:** Select the operation mode of the signal outputs when the relay is active:
- Cont.:* Signal outputs continue to issue the measured value.
- Hold:* Signal outputs issue the last valid measured value. Measurement is interrupted. Errors, except fatal errors, are not issued.
- Off:* Set to 0 or 4 mA respectively. Errors, except fatal errors, are not issued.
- 5.3.4.3 **Output/Control:** (relay or signal output):
- Cont.:* Controller continues normally.
- Hold:* Controller continues on the last valid value.
- Off:* Controller is switched off.
- 5.3.4.4 **Fault:**
- No:* No message is issued in pending error list and the alarm relay does not close when input is active. Message E024 is stored in the message list.
- Yes:* Message E024 is issued and stored in the message list. The Alarm relay closes when input is active.
- 5.3.4.5 **Delay:** Time which the instrument waits, after the input is deactivated, before returning to normal operation.  
Range: 0–6'000 sec

## 5.4 Miscellaneous

- 5.4.1 **Language:** Set the desired language.  
Available settings: German /English/French/Spanish
- 5.4.2 **Set defaults:** Reset the instrument to factory default values in three different ways:
- ◆ **Calibration:** Sets calibration values back to default. All other values are kept in memory.
  - ◆ **In parts:** Communication parameters are kept in memory. All other values are set back to default values.
  - ◆ **Completely:** Sets back all values including communication parameters.
- 5.4.3 **Load Firmware:** Firmware updates should be done by instructed service personnel only.

- 5.4.4 Access:** Select a password to prevent unauthorized access to the menus <Messages>, <Diagnostics>, <Maintenance>, <Operation> and <Installation>.

**Note:** *The password protection becomes active under the following conditions:*

- Enter an administrator password different from <0000>.
- After defining the administrator password, users 1–4 are also automatically activated. The default password for all users is <1234>. If necessary, change the passwords.

- 5.4.4.1 Administrator:** The administrator owns all rights and has access to all menus. Only an administrator can assign user rights for the users 1 to 4.

Name: Admin predefined, not changeable  
 Function: Administrator predefined, not changeable

- 5.4.4.1.3 Password:** The password is set to <0000> by default. If an administrator password different from <0000> is set, it is not longer possible to enter a menu without entering the password. If you have forgotten the administrator password, contact your nearest SWAN representative or the manufacturer.

**5.4.4.2 User 1**

- 5.4.4.2.1 Name:** Enter the name of the user.

- 5.4.4.2.2 Function:**

Function
Administrator
Service
Operator

Administrator: All rights

Service: Access to all menus except menu <Installation>

Operator: Access to the menus <Messages> and <Diagnostic>

**5.4.4.3 User 2**

see User 1

**5.4.4.4 User 3**

see User 1

**5.4.4.5 User 4**

see User 1

5.4.5 *Sample ID*: Identify the process value with any meaning full text, such as KKS number.

5.4.6 *Line Break Detection*: If activated, error message E028 is shown in case of line break on signal outputs 1 and 2.

## 5.5 Interface

Select one of the following communication protocols. Depending on your selection, different parameters must be defined.

### 5.5.1 Protocol: **Profibus**

5.5.20 Device address: Range: 0–126

5.5.30 ID-Nr.: Range: Analyzer; Manufacturer; Multivariable

5.5.40 Local operation: Range: Enabled, Disabled

### 5.5.1 Protocol: **Modbus RTU**

5.5.21 Device address: Range: 0–126

5.5.31 Baud Rate: Range: 1200–115 200 Baud

5.5.41 Parity: Range: none, even, odd

### 5.5.1 Protocol: **USB stick**

Only visible if an USB interface is installed. No further settings are possible.

### 5.5.1 Protocol: **HART**

5.5.24 Device address: Range: 0–63

## **10. Material Safety Data Sheets**

### **10.1. Reagents**

Catalogue No.: A-85.410.210  
Product name: OXYCON ON-LINE DPD

Catalogue No.: A-85.410.210  
Product name: OXYCON ON-LINE Buffer O3

**Download  
MSDS**      The current Material Safety Data Sheets (MSDS) for the above listed  
Reagents are available for downloading at **[www.swan.ch](http://www.swan.ch)**.

## 11. Default Values

### Operation:

Sensors:	Verification kits: Verikit low: .....	0.0900
	Verification kits: Verikit high: .....	0.1800
	Filter Time Const.: .....	30 s
	Hold after Cal.: .....	120 s
	Meas. Interval: .....	6 min
Alarm Relay	.....	same as in Installation
Relay 1 and 2	.....	same as in Installation
Input	.....	same as in Installation
Logger:	Logger Interval: .....	event driven
	Clear Logger: .....	no

### Installation:

Sensors	Disinf: .....	Ozone
	Reag. expiry warning .....	yes
Signal Output 1	Parameter: .....	DIS.
	Current loop: .....	4–20 mA
	Function: .....	linear
	Scaling: Range low: .....	0.0 ppb
	Scaling: Range high: .....	500.0 ppb
Signal Output 2	Parameter: .....	Sample flow
	Current loop: .....	4–20 mA
	Function: .....	linear
	Scaling: Range low: .....	0 B/s
	Scaling: Range high: .....	200 B/s
Alarm Relay	Alarm DIS.: .....	
	Alarm high: .....	500.0 ppb
	Alarm low: .....	0.0 ppb
	Hysteresis: .....	1.0 ppb
	Delay: .....	5 s
	Sample Flow: Flow Alarm: .....	yes
	Sample Flow: Alarm High: .....	500 B/s
	Sample Flow: Alarm Low: .....	5 B/s
	Case temp. high: .....	65 °C
	Case temp. low: .....	0 °C
Relay 1 and 2	Function: .....	Limit upper
	Parameter: .....	DIS.
	Setpoint: .....	500.0 ppb

Hysteresis: ..... 1.0 ppb  
Delay: ..... 30 s

### If Function = Control upw. or dnw:

Parameter: ..... **DIS**  
Settings: Actuator: ..... Frequency  
Settings: Pulse Frequency: ..... 120/min  
Settings: Control Parameters: Setpoint: ..... 500.0 ppb  
Settings: Control Parameters: P-band: ..... 1.0 ppb

Parameter: ..... **Sample Flow**  
Settings: Actuator: ..... Frequency  
Settings: Pulse Frequency: ..... 120/min  
Settings: Control Parameters: Setpoint: ..... 200 B/s  
Settings: Control Parameters: P-band: ..... 20 B/s

### Common settings

Settings: Control Parameters: Reset time: ..... 0 s  
Settings: Control Parameters: Derivative Time: ..... 0 s  
Settings: Control Parameters: Control Timeout: ..... 0 min

Settings: Actuator: ..... Time proportional  
Cycle time: ..... 60 s  
Response time: ..... 10 s  
Settings: Actuator: ..... Motor valve  
Run time: ..... 60 s  
Neutral zone: ..... 5%

### If Function = Timer:

Mode: ..... Interval  
Interval: ..... 1 min  
Mode: ..... daily  
Start time: ..... 00.00.00  
Mode: ..... weekly  
Calendar; Start time: ..... 00.00.00  
Calendar; Monday to Sunday: ..... Off  
Run time: ..... 10 s  
Delay: ..... 5 s  
Signal output: ..... cont  
Output/Control: ..... cont

Input:	Active.....	when closed
	Signal Outputs .....	hold
	Output/Control .....	off
	Fault.....	no
	Delay .....	10 s
Miscellaneous	Language:.....	English
	Set default: .....	no
	Load firmware:.....	no
	Access: Password: Administrator .....	0000
	Access: Password: User 1 ...4:.....	1234
	Sample ID:.....	- - - - -
	Line break detection .....	no



## 12. Index

### A

Alarm	
DIS . . . . .	77
Sample flow . . . . .	77
Alarm Relay . . . . .	11, 27, 76
Application range . . . . .	11

### C

Cable thicknesses . . . . .	22
Calendar . . . . .	81
Calibration	
DIS . . . . .	50, 71
Changing values . . . . .	40
Current outputs . . . . .	30

### E

Electrical wiring . . . . .	18
-----------------------------	----

### F

Fill System. . . . .	35, 71
Flow Alarm . . . . .	57, 77
Fluidics. . . . .	12

### H

HART . . . . .	32
----------------	----

### I

Input . . . . .	11, 27
Instrument Setup . . . . .	18
Interface	
HART . . . . .	32
Modbus. . . . .	31
Profibus . . . . .	31
USB. . . . .	32

### L

Logger. . . . .	72, 86
-----------------	--------

### M

Measurement interval . . . . .	44, 72, 86
Measuring range. . . . .	15
Message List . . . . .	69
Modbus . . . . .	31
Mounting requirements . . . . .	19

### O

On-site requirements . . . . .	15, 18
--------------------------------	--------

### P

Password . . . . .	83
Pending Errors . . . . .	69
pH offset . . . . .	57
Power Supply . . . . .	15
Process DIS . . . . .	36, 50, 71
Profibus . . . . .	32

### R

Reagent consumption. . . . .	44
Relay . . . . .	11, 77, 86

### S

Sample Flow . . . . .	34, 70, 77
Sample requirements . . . . .	15
Signal Outputs . . . . .	11, 30, 73
Simulation . . . . .	71
Slope photometry . . . . .	57
Software . . . . .	39

### T

Terminals . . . . .	24, 27–28, 31
---------------------	---------------

<b>U</b>	
USB Interface . . . . .	32
<b>V</b>	
Ver. History . . . . .	70
Verification . . . . .	46, 71
<b>W</b>	
Wire . . . . .	22
<b>Z</b>	
Zero photometry . . . . .	57

## This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

**Swan Products - Analytical Instruments for:**



**Swan** is represented worldwide by subsidiary companies and distributors and cooperates with independent representatives all over the world. For contact information, please scan the QR code.

Swan Analytical Instruments · CH-8340 Hinwil  
[www.swan.ch](http://www.swan.ch) · [swan@swan.ch](mailto:swan@swan.ch)

**SWISS  MADE**

