

Complete monitoring system for the automatic, continuous measurement of the specific conductivity, concentration of CIP solutions, salinity and TDS in surface water, potable water and cooling water.

## Monitor AMI Solicon4

Complete system mounted on PVC mounting panel:


- **Transmitter AMI Solicon4** in a rugged aluminum enclosure (IP 66).
- **Flow cell M-Flow PG.**
- **Swansensor Shurecon P;** 4-electrode conductivity sensor with integrated Pt1000 temperature sensor.
- Factory tested, ready for installation and operation.

Optional:

- Swansensor deltaT for flow detection

### Specifications:

- Simultaneous measurement and display of conductivity, sample temperature and sample flow.
- Measurement range from 0.1  $\mu\text{S}/\text{cm}$  to 100  $\text{mS}/\text{cm}$ .
- For the measurement of specific conductivity, concentrations (for NaCl, NaOH and acids in %), salinity (as NaCl in %) and total dissolved solids (TDS in % or  $\text{mg}/\text{l}$ ).
- Conductivity sensor unaffected by fouling. No measuring errors due to polarization effects.
- Straightforward sensor calibration without sensor removal directly in flow cell with quick release vessel and user guided dialogue.
- Large backlit LCD display for the reading of measuring value, sample temperature, sample flow and operating status.
- Easy user menus in English, German, French and Spanish. Simple programming of all parameters by keypad.
- Two current signal outputs (0/4 – 20mA) for measured signals.
- Data logger for 1'500 data records stored at a selectable interval. (Data download to PC requires optional HyperTerminal interface)



**Monitor AMI Solicon4**  
with optional deltaT flow  
detection.

Order Nr.	Monitor AMI Solicon4	A-23.421.020
Option 1:	<input type="checkbox"/> 3 <sup>rd</sup> current signal output (0/4 – 20mA) <input type="checkbox"/> Profibus DP interface <input type="checkbox"/> HyperTerminal interface (RS-232) <input type="checkbox"/> Modbus interface <input type="checkbox"/> USB interface	A-81.410.020 A-81.420.020 A-81.420.010 A-81.420.022 A-81.420.040
Option 2:	<input type="checkbox"/> Swansensor deltaT Flow	A-87.933.010

## Conductivity Measurement

**Swansensor Shurecon P** with integrated Pt1000 temperature sensor.

Measuring range	Resolution
0.10 to 9.99 $\mu\text{S/cm}$	0.01 $\mu\text{S/cm}$
10.0 to 99.9 $\mu\text{S/cm}$	0.1 $\mu\text{S/cm}$
100 to 999 $\mu\text{S/cm}$	1 $\mu\text{S/cm}$
1.00 to 9.99 $\text{mS/cm}$	0.01 $\text{mS/cm}$
10.0 to 29.9 $\text{mS/cm}$	0.1 $\text{mS/cm}$
30 to 100 $\text{mS/cm}$	1 $\text{mS/cm}$
Automatic range switching.	

**Accuracy**  $\pm 0.5\%$  of measured value

### Temperature compensations

Absolute (none), linear coefficient in  $\%^\circ\text{C}$ , non linear function (NLF) for natural waters according to EN 27888 / DIN 38404

### Concentration measurements (25°C)

- NaCl:	0 - 4.6%
- HCl:	0 - 0.8%
- NaOH:	0 - 1.6%
- $\text{H}_2\text{SO}_4$ :	0 - 1.1%
- $\text{HNO}_3$ :	0 - 1.5%
- Salinity:	0 - 4.6% (as NaCl)
- TDS:	0 - 4.6% (as NaCl)
- TDS: 0.0 mg/l – 20 g/l (with coefficient)	

### Temperature measurement

With Pt1000 type sensor.

Measuring range:	-30 to +130°C
Resolution:	0.1°C

### Sample flow measurement (option)

With digital SWAN sample flow meter.

## Transmitter Specifications and Functionality

Electronics case:	Aluminum
Protection degree:	IP 66 / NEMA 4X
Display:	backlit LCD, 75 x 45 mm
Electrical connectors:	screw clamps
Ambient temperature:	-10 to +50°C
Limit range of operation:	-25 to +65°C
Storage and transport:	-30 to +85°C
Humidity:	10 to 90 % relative non condensing

### Power supply

Voltage:	100 - 240 VAC ( $\pm 10\%$ ), 50/60 Hz ( $\pm 5\%$ ) or 24 VDC ( $\pm 10\%$ )
Power consumption:	max. 30 VA

### Operation

Easy operation based on separate menus for "Messages", "Diagnostics", "Maintenance", "Operation" and "Installation".


Separate menu specific password protection possible.

Display of process value, sample flow, alarm status and time during operation.

Storage of event- and alarm log.

Storage of the last 1'500 data records in log with selectable time interval.

## Electrical Connection Scheme



### Safety features

No data loss after power failure, all data is saved in non-volatile memory.

Overvoltage protection of in- and outputs.

Galvanic separation of measuring inputs and signal outputs.

### Transmitter temperature monitoring

With programmable high/low alarm limits

### Real-time clock with calendar

For action time stamp and preprogrammed actions.

#### 1 Alarm relay

One potential free contact for summary alarm indication for programmable alarm values and instrument faults.

Maximum load: 1A / 250 VAC

#### 1 Input

One input for potential-free contact. Programmable hold or remote off function.

#### 2 Relay outputs

Two potential-free contacts programmable as limit switches for measuring values, controllers or timer for system cleaning with automatic hold function.

Max. load: 1A / 250 VAC

#### 2 Signal outputs (3<sup>rd</sup> as option)

Two programmable signal outputs for measured values (freely scaleable, linear or bilinear) or as continuous control outputs (control parameters programmable).

Current loop: 0/4 - 20 mA

Maximum burden: 510  $\Omega$

### Control functions

Relays or current outputs programmable for 1 or 2 pulse dosing pumps, solenoid valves or for one motor valve.

Programmable P, PI, PID or PD control parameters.

### 1 Communication interface (option)

- RS232 interface for logger download to PC with SWANTerminal
- RS485 interface (galvanically separated) with Fieldbus protocol Modbus or Profibus DP
- 3<sup>rd</sup> Signal output
- USB interface

## Monitor Data

### Sample conditions

Flow rate:	4 to 15 l/h
Temperature:	up to 50 °C
Inlet pressure (25 °C):	up to 1 bar
Outlet pressure:	pressure free

### Sample connections

Sample inlet: Hose nozzle 1/4" -10 elbow for 10mm tube

Sample outlet: G 1/2" adapter for flexible tube  $\varnothing$  20 x 15 mm

Panel dimensions: 280 x 850 x 180 mm

Panel material: white PVC

Weight: 9.0 kg