

AMI Soditrace

On-Line Analyzer for the Continuous Measurement of Sodium Ions in Trace Amounts in Steam and High Purity Water

- *Lowest detection limit for sodium ion concentration: 0.001 ppb*
- *Automatic 3-point known addition calibration in ppb range*
- *Automatic regeneration of sodium electrode (patent pending)*
- *Automatic control of sample pH conditioning and temperature compensation*
- *Optional communication board Profibus DP / Modbus*
- *Factory tested and ready for installation and operation.*



Sodium Measurement in the ppt-Range

Monitor AMI Soditrace
Data Sheet Nr. DenA2461X0X0



Sodium Measurement in the ppt-Range



Monitor AMI Soditrace
Data Sheet Nr. DenA2461X0X0

Analytical System

- *Measuring range:*
0,001 ppb – 10 ppm
- *Accuracy:*
 ± 0.005 ppb or $\pm 10\%$ of reading
- *Reproducibility:*
 ± 0.001 ppb or $\pm 5\%$ of reading
- *Response Time:*
120 s (90%)

Continuous Monitoring of:

- *Reagent exhaustion*
- *Sample Flow*
- *Sample Temperature.*

AMI Electronic Unit

- *Rugged aluminium housing IP66*
- *Two freely scalable current signal outputs (0/4 - 20 mA), third one as an option*
- *Optional fieldbus communication board.*

Made in Switzerland



swan
ANALYTICAL INSTRUMENTS