

AMI INSPECTOR Oxygen

Version 6.00 and higher



Operator's Manual



Customer Support

SWAN and its representatives maintain a fully trained staff of technical specialists around the world. For any technical question, contact your nearest SWAN representative, or the manufacturer:

SWAN ANALYTISCHE INSTRUMENTE AG
Studbachstrasse 13
8340 Hinwil
Switzerland
Internet: www.swan.ch
E-mail: support@swan.ch

Document Status

Title:	AMI INSPECTOR Oxygen Operator's Manual	
ID:	A-96.250.701	
Revision	Issue	
00	Sep. 2011	First Edition
01	Nov. 2013	New main board, integrated USB interface
02	Jan. 2016	AMI Inspector Version 2-A (with AMIAKKU main-board) and Firmware version 6.00

Table of Contents

1. Safety Instructions 3

1.1. Warning Notices 4

1.2. General Safety Regulations 6

2. Product Description 7

2.1. Description of the System 7

2.2. Instrument Overview 10

2.3. Technical Data 11

3. Installation 13

3.1. Installation Check List 13

3.2. Connecting Sample Inlet and Outlet 14

3.2.1 Connect the Sample Inlet to the Quick-Lock Coupling 14

3.2.2 Connect the Sample Outlet 15

3.3 Install the Swansensor Oxytrace G 16

3.4. Electrical Connections 17

3.5. Connection Diagram 18

3.5.1 Power Supply 19

3.6. Relay Contacts 21

3.6.1 Input 21

3.6.2 Alarm Relay 21

3.6.3 Relay Contacts 1 and 2 22

3.7. Signal Output 22

4. Instrument Setup 23

4.1. Establish sample flow 23

4.2. Programming 23

5. Operation 24

5.1. Keys 24

5.2. Display 25

5.3. Software Structure 26

5.4. Changing Parameters and values 27

6.	Maintenance	28
6.1.	Maintenance Table	28
6.2.	Stop of Operation for Maintenance	28
6.3.	Maintenance of the Oxygen Sensor	29
6.3.1	Electrolyte exchange	29
6.3.2	Clean Swansensor Oxytrace and G Flow Cell	31
6.4.	Calibration	32
6.5	Zero-Verification	34
6.6.	Quality Assurance of the Instrument	34
6.6.1	Activate SWAN Quality assurance procedure	36
6.6.2	Pre-test	36
6.6.3	Connect the sample lines	36
6.6.4	Carry out comparison measurement	38
6.6.5	Completion of the measurement	39
6.7.	Replacing Fuses	40
6.8.	Replacing the Battery	41
6.9.	Longer Stop of Operation	41
7.	Error List	42
8.	Program Overview	45
8.1.	Messages (Main Menu 1)	45
8.2.	Diagnostics (Main Menu 2)	46
8.3.	Maintenance (Main Menu 3)	47
8.4.	Operation (Main Menu 4)	48
8.5.	Installation (Main Menu 5)	48
9.	Program List and Explanations	50
	1 Messages	50
	2 Diagnostics	50
	3 Maintenance	52
	4 Operation	53
	5 Installation	54
10.	Default Values	69
11.	Index	72
12.	Notes	73

AMI INSPECTOR Oxygen - Operator's Manual

This document describes the main steps for instrument setup, operation and maintenance.

1. Safety Instructions

General The instructions included in this section explain the potential risks associated with instrument operation and provide important safety practices designed to minimize these risks.
If you carefully follow the information contained in this section, you can protect yourself from hazards and create a safer work environment.

More safety instructions are given throughout this manual, at the respective locations where observation is most important.

Strictly follow all safety instructions in this publication.

Target audience Operator: Qualified person who uses the equipment for its intended purpose.
Instrument operation requires thorough knowledge of applications, instrument functions and software program as well as all applicable safety rules and regulations.

OM Location The AMI Operator's Manual shall be kept in proximity of the instrument.

Qualification, Training To be qualified for instrument installation and operation, you must:

- ◆ read and understand the instructions in this manual as well as the Material Safety Data Sheets.
- ◆ know the relevant safety rules and regulations.

1.1. Warning Notices

The symbols used for safety-related notices have the following significance:



DANGER

Your life or physical wellbeing are in serious danger if such warnings are ignored.

- ♦ Follow the prevention instructions carefully.



WARNING

Severe injuries or damage to the equipment can occur if such warnings are ignored.

- ♦ Follow the prevention instructions carefully.



CAUTION

Damage to the equipment, minor injury, malfunctions or incorrect process can be the consequence if such warnings are ignored.

- ♦ Follow the prevention instructions carefully.

Mandatory Signs

The importance of the mandatory signs in this manual.



Safety goggles



Safety gloves

Warning Signs The importance of the warning signs in this manual.



Electrical shock hazard



Corrosive



Harmful to health



Flammable



Warning general



Attention general

1.2. General Safety Regulations

Legal Requirements

The user is responsible for proper system operation. All precautions must be followed to ensure safe operation of the instrument.

Spare Parts and Disposables

Use only official SWAN spare parts and disposables. If other parts are used during the normal warranty period, the manufacturer's warranty is voided.

Modifications

Modifications and instrument upgrades shall only be carried out by an authorized Service Technician. SWAN will not accept responsibility for any claim resulting from unauthorized modification or alteration.

WARNING



Risk of Electrical Shock

If proper operation is no longer possible, the instrument must be disconnected from all power lines, and measures must be taken to prevent inadvertent operation.

- ♦ To prevent from electrical shock, always make sure that the ground wire is connected.
- ♦ Service shall be performed by authorized personnel only.
- ♦ Whenever electronic service is required, disconnect instrument power and power of devices connected to.
 - relay 1,
 - relay 2,
 - alarm relay



WARNING

For safe instrument installation and operation you must read and understand the instructions in this manual.



WARNING

Only SWAN trained and authorized personnel shall perform the tasks described in this document.

2. Product Description

This chapter contains technical data, requirements and performance data.

2.1. Description of the System

The portable AMI INSPECTOR instrument is a complete monitoring system mounted on a small panel with supporting stand and a rechargeable battery for stand-alone operation (>24h), designed as an inspection equipment for quality assurance of online process monitors.

Features	General Features of AMI INSPECTORs are: ♦ Battery life after full charge: – >24h at full load (use of 3 relays, USB, signal output, logger) – >36h at minimum load (use of logger only) ♦ Charging time: approx. 6 hours ♦ Controlled shut-down if battery is empty. ♦ Display of remaining battery life in hours. ♦ For longer battery life the back light of the LC Display is disabled. ♦ Continuous operation using power adapter. The battery should be discharged at least once a month (normal usage until the monitor automatically shuts down).
Battery	The Li-Ion battery is located in the housing of the AMI transmitter. See chapter Power Supply, p. 19 regarding power supply and charging of the battery.
Safety features	No data loss after power failure, all data is saved in non-volatile memory. Over voltage protection of in- and outputs. Galvanic separation of measuring inputs and signal outputs.
USB interface	Built in USB interface for logger download. Use the USB stick supplied by Swan only (other USB sticks can dramatically reduce battery life).
Signal Output	One signal output programmable for measured values (freely scaleable, linear or bilinear) or as continuous control output (control parameters programmable). Current loop: 0/4–20 mA Maximal burden: 510 Ω

Relay Two potential-free contacts programmable as limit switches for measuring values, controllers or timer for system cleaning with automatic hold function.

Maximum load: 100 mA/50 V

Alarm Relay One potential free contact.

Alternatively:


- ♦ Open during normal operation, closed on error and loss of power.
- ♦ Closed during normal operation, open on error and loss of power.

Summary alarm indication for programmable alarm values and instrument faults.

Input For potential-free contact to freeze the measuring value or to interrupt control in automated installations (hold function or remote-off)

Measuring principle Clark principle:
The sensor consists of one noble metal electrode (e.g. platinum or gold), a reference electrode (mostly Ag/AgCl) and optionally a metal guard electrode.

The Clark-type electrode is the most widely used oxygen sensor for measuring oxygen dissolved in a liquid. The basic principle is that there is a cathode and an anode submersed in an electrolyte and a voltage is applied between the two parts. Oxygen enters the sensor through a permeable membrane by diffusion, and is reduced at the cathode according to




This reaction creates a measurable current. There is a linear correlation between the oxygen concentration and the electrical current.

The guard electrode is on the same voltage level as the cathode but there is no current measurement. Oxygen which diffuses from the electrolyte to the cathode is consumed by the guard electrode. As a consequence, residual oxygen in the electrolyte will no more disturb the measurement signal and the response time to low oxygen levels will be shorter.

Temperature compensation The measuring signal depends on temperature, but is automatically compensated to 25 °C. The sample temperature is determined continuously by a temperature sensor inside the oxygen electrode.

Fluidics Swansensor oxygen combined with QV-flow PMMA OTG flow cell. The sample flows via sample inlet [E] through the flow regulating valve [D], where the flow rate can be adjusted. Then the sample flows into the measuring cell [C] where the Oxygen concentration and temperature of the sample is measured. The sample leaves the measuring cell via flow sensor [B] through the sample outlet [F].



A Oxygen sensor
B Flow sensor
C Flow cell


D Flow regulating valve
E Sample inlet
F Sample outlet

AMI INSPECTOR Oxygen

Product Description

swan
ANALYTICAL INSTRUMENTS

2.2. Instrument Overview



A AMI Transmitter
B Oxygen sensor
C Flow cell
D Flow sensor
E Flow regulating valve

F Sample inlet
G Sample outlet

2.3. Technical Data

Power Supply	Battery
	Use original, supplied power adapter only.
	Voltage: 85–265 VAC, 50/60 Hz
	Power consumption: max. 20 VA
	Charging time: 6h
	Battery type: Li-Ion
	During charging protect from heat impact and keep splash-proof (not IP66).
Operating time	Stand-alone (Battery): > 24h
	Connected adapter: continuous
	Controlled shut-down when battery is empty, remaining time is displayed.
Electronics housing	Aluminium with a protection degree of IP 66 / NEMA 4X
	Ambient temperature: -10 to +50 °C
	Humidity: 10–90% rel., non condensing
	Display: backlit LCD, 75 x 45 mm
Sample requirements	Flow rate: 8 to 25 l/h
	Temperature: up to 45 °C
	Inlet pressure: 0.2 to 1 bar
	pH: not lower than pH 4
	Suspended solids: less than 10 ppm
	Outlet pressure: pressure free
Flow cell and connection	Flow cell made of acrylic glass with built-in flow adjustment valve and digital sample flow meter
	Sample inlet: 1/4" Swagelok tube adapter
	Sample outlet: flexible tube 8x6 mm
Accuracy	±1.5 % of measured value or ±0.2 ppb
Reproducibility	±1 % of measured value or ±0.15 ppb

AMI INSPECTOR Oxygen

Product Description

Sensor
Oxytrace G Sensor for the measurement of dissolved oxygen in ultra pure water. Precise oxygen measuring cell with integrated temperature sensor and guard electrode for faster initial response time after maintenance.

Technical data: Clark oxygen electrode
Cathode gold, anode silver, guard silver
Zero current-free electrode system
Robust 25 µm fluoropolymer diaphragm

Measuring range: 0–20 ppm O₂ (25 °C)
Automatic range switching

Range	Resolution
0.1 to 9.99 ppb	0.01 ppb
10 to 199.9 ppb	0.1 ppb
200 to 1999 ppb	1.0 ppb
2 to 20 ppm	0.01 ppm
0 – 200% saturation	

Accuracy: 0,3 % if calibration temperature = measuring temp. 1,5% at ± 10 °C deviation to cal. temperature

Precision: ± 1% of reading or ±0.15 ppb

Response time: t₉₀ < 30 seconds (rising concentration)

Minimal flow: 50 cm/s Pressure resistance: 3 bar

Operating temperature: max. 50 °C

Material: polyacetal copolymer

Protection: IP 68

Weight: 150 g

3. Installation


3.1. Installation Check List

Check	♦ Instrument's specification must conform to your AC power ratings. See External power adapter, p. 20. ♦ Check if the battery is fully charged.
Installation	♦ Connect the sample inlet and outlet, see Connecting Sample Inlet and Outlet, p. 14. ♦ Install the Swansensor Oxytrace G into the flow cell, see Install the Swansensor Oxytrace G, p. 16.
Power-up	♦ Open the flow regulating valve and adjust the sample flow to 8–25 l/h. ♦ Switch on power.
Instrument Setup	♦ Program all parameters, see chapter 4.
Run-in period	♦ Let the instrument run continuously for 1 h.

3.2. Connecting Sample Inlet and Outlet

3.2.1 Connect the Sample Inlet to the Quick-Lock Coupling


The AMI INSPECTOR Oxygen is delivered with a quick-lock coupling. To connect the sample line to the AMI INSPECTOR Oxygen, simply push the nipple into the quick-lock coupling.



3.2.2 Connect the Sample Outlet

Installation

- 1 Loosen the union nut [B] but do not remove it.
- 2 Push the FEP tube [A] through the union nut [B] as far as it reaches the stop of the threaded tube [E].
- 3 Tighten the union nut $1\frac{3}{4}$ rotation using an open ended spanner. Hold Body from turning with a second wrench.
- 4 Put the FEP Tube into a pressure free drain with sufficient capacity.



A FEP tube 8x6

B Union nut

C Compression ferrule


D Compression cone

E Threaded tube

F Tightened connection

3.3 Install the Swansensor Oxytrace G

The Swansensor Oxytrace G is delivered with prefilled electrolyte chamber [E]. A transport protection cap [B] filled with water [D] keeps the sensor wet during transport and storage. To install the sensor proceed as follows:



- 1 Unscrew the fixing sleeve [A].
- 2 Remove the transport protection cap [B].
- 3 Clean the Swansensor Oxytrace G [C] with water.
- 4 Install the Swansensor Oxytrace G into the flow cell
Connect the sensor cable to the transmitter, see [Connection Diagram, p. 18](#).

3.4. Electrical Connections




WARNING

Always turn off DC power before manipulating electric parts. Make sure the power specification of the instrument corresponds to the power on site.

Cable thicknesses

In order to comply with IP66, use the following cable thicknesses



A PG 9 cable gland: cable $\varnothing_{outer}$ 4–8 mm

B PG 7 cable gland: cable $\varnothing_{outer}$ 3–6.5 mm

NOTICE: Protect unused cable glands

Wire

- ♦ For Relays: Use max. 1.5 mm² / AWG 14 stranded wire with end sleeves.
- ♦ For Signal Outputs and Input: Use 0.25 mm² / AWG 23 stranded wire with end sleeves.




WARNING

External Voltage.

External supplied devices connected to relay 1 or 2 or to the alarm relay can cause electrical shocks.

- ♦ Make sure that the devices connected to the following contacts are disconnected from the power before continuing the installation.
 - relay 1
 - relay 2
 - alarm relay

3.5. Connection Diagram



CAUTION



Use only the terminals shown in this diagram, and only for the mentioned purpose. Use of any other terminals will cause short circuits with possible corresponding consequences to material and personnel.

3.5.1 Power Supply

Contrary to all other Swan online process monitors the AMI INSPECTOR transmitter is supplied with power by battery only. The rechargeable battery (Li-Ion) enables a stand-alone operation for at least 24 hours.



WARNING

Do not provide power directly to the transmitter as this will destroy the motherboard. All AMI INSPECTOR transmitters are supplied with power by battery only.

Charging

Use the original supplied power adapter to charge AMI INSPECTOR only. Charging time: approx 6h.

Fully charged a stand-alone operating time of at least 24h is guaranteed:

- ♦ >24h at full load (use of 3 relays, USB, signal output, logger)
- ♦ >36h at minimal load (use of logger only)

In case that the battery is discharged completely the firmware will automatically shut down.

Switch Power ON - OFF

Switch the instrument ON or OFF using the toggle switch on the transmitter.

Continuous operation

For continuous operation use the power adapter as well.



CAUTION

- ♦ If the AMI powers ON and then immediately shuts OFF, the battery is empty. Do not hold the toggle switch in ON position, as this can damage the battery.



CAUTION

- ♦ During charging protect from heat impact and keep splash-proof (plug of power adapter is not IP66).
- ♦ Do not supply external devices, e.g. pumps, magnetic valves or any other current consumers with AMI INSPECTOR



CAUTION

- ♦ Use the original supplied power adapter to charge AMI INSPECTOR only. Use of any other power adapter can damage the battery or cause malfunction.

AMI INSPECTOR Oxygen

Installation

External power adapter

- ♦ Universal input range 85 - 265 VAC
- ♦ Continuous short circuit protection
- ♦ Over voltage protection
- ♦ LED indicator for power on
- ♦ 2-pin AC inlet (IEC 320-C8) for country-specific power cord




Power cords

Two different power cords are supplied:

- ♦ Power cord with type C plug (Europlug)
- ♦ Power cord with type A plug (NEMA-1)

If a different plug type is needed, please purchase a suitable power cord from your local supplier.

Dimensions



3.6. Relay Contacts

Programming of the relay contacts see [5.3 Relay Contacts, p. 59](#)

3.6.1 Input

NOTICE: Use only potential-free (dry) contacts.

Terminals 13/14

If signal output is set to hold, measurement is interrupted if input is active.

For programming see menu [5.3.4, p. 65](#)

3.6.2 Alarm Relay

NOTICE: For resistive loads only; do not use with capacitive or inductive loads. Max. load 1 A / 250 VAC.

Alarm output for system errors.

Error codes see [Error List, p. 42](#)

Programming see menu [5.3.1, p. 59](#)

NOTICE: With certain alarms and certain settings of the AMI transmitter the alarm relay does not switch. The error, however, is shown on the display.


	Terminals	Description	Relay connection
NC¹⁾ Normally Closed	5/4	Active (opened) during normal operation. Inactive (closed) on error and loss of power.	
NO Normally Open	5/3	Active (closed) during normal operation. Inactive (opened) on error and loss of power.	

¹⁾ usual use

3.6.3 Relay Contacts 1 and 2

NOTICE: For resistive loads only; do not use with capacitive or inductive loads. Rated load 100 mA/ 50 V

For programming see Menu Installation 5.3.2 and 5.3.3, p. 61

	Terminals	Description	Relay connection
NO Normally Open	6/7: Relay 1 8/9: Relay 2	Inactive (opened) during normal operation and loss of power. Active (closed) when a programmed function is executed.	


3.7. Signal Output

The signal output 0/4–20 mA PCB is plugged onto the USB interface PCB.

NOTICE: Max. burden 510 Ω .

Terminals 16 (+) and 15 (-).

For programming see menu 5.2 Signal Outputs, p. 55.



A Signal output 0/4–20 mA PCB
B USB interface

4. Instrument Setup

4.1. Establish sample flow

- 1 Open flow regulating valve, see [Fluidics, p. 9](#).
- 2 Wait until the flow cell has been completely filled.
- 3 Switch on power.
- 4 Adjust the sample flow to 8–25 l/h.
- 5 Let the instrument run-in for 1 h.

4.2. Programming


Programming

Program all parameters for external devices (interface, recorders, etc.)

Program all parameters for instrument operation (limits, alarms), see [Program List and Explanations, p. 50](#)


5. Operation

5.1. Keys




- A** to exit a menu or command (rejecting any changes)
to move back to the previous menu level
- B** to move DOWN in a menu list and to decrease digits
- C** to move UP in a menu list and to increase digits
- D** to open a selected sub-menu
to accept an entry

Program Access, Exit



5.2. Display



- | | | |
|----------|--|---|
| A | RUN | normal operation |
| | HOLD | input closed or cal delay: Instrument on hold (shows status of signal outputs). |
| | OFF | input closed: control/limit is interrupted (shows status of signal outputs). |
| B | ERROR |  Error  Fatal Error |
| C | Relay status | |
| D | Battery status (remaining operating time in h) | |
| E | Time | |
| F | Process values | |
| G | Sample Temperature | |

Relay status, symbols

- | | |
|---|--|
|  | upper limit not yet reached |
|  | lower limit not yet reached |
|  | upper limit reached |
|  | lower limit reached |
|  | control upw./downw. no action |
|  | control upw./downw. active, dark bar indicates control intensity |
|  | motor valve closed |
|  | motor valve: open, dark bar indicates approx. position |
|  | timer |
|  | timer: timing active (hand rotating) |

5.3. Software Structure

Main Menu	1
Messages	▶
Diagnostics	▶
Maintenance	▶
Operation	▶
Installation	▶

Messages	1.1
Pending Errors	▶
Maintenance List	▶
Message List	▶

Menu **Messages 1**

Reveals pending errors as well as an event history (time and state of events that have occurred at an earlier point of time).
It contains user relevant data.

Diagnostics	2.1
Identification	▶
Sensors	▶
Sample	▶
I/O State	▶
Interface	▶

Menu **Diagnostics 2**

Provides user relevant instrument and sample data.

Maintenance	3.1
Calibration	▶
Service	▶
Simulation	▶
Set Time	23.09.06 16:30:00

Menu **Maintenance 3**

For instrument calibration, relay and signal output simulation, and to set the instrument time.
It is used by the service personnel.

Operation	4.1
Sensors	▶
Relay Contacts	▶
Logger	▶

Menu **Operation 4**

User relevant parameters that might need to be modified during daily routine. Normally password protected and used by the process-operator.
Subset of menu 5 - Installation, but process-related.

Installation	5.1
Sensors	▶
Signal Outputs	▶
Relay Contacts	▶
Miscellaneous	▶
Interface	▶

Menu **Installation 5**

For initial instrument set up by SWAN authorized person, to set all instrument parameters. Can be protected by means of password.

5.4. Changing Parameters and values

Changing parameters

The following example shows how to change the logger interval:

Logger 4.4.1
Log interval 30 min
Clear logger no

1 Select the parameter you want to change.

2 Press [Enter]

Logger 4.1.3
Log inten Interval.
Clear log 5 min
10 min
30 min
1 Hour

3 Press [▲] or [▼] key to highlight the required parameter.

4 Press [Enter] to confirm the selection or [Exit] to keep the previous parameter).

Logger 4.1.3
Log interval 10 min
Clear logger no

⇒ The selected parameter is highlighted (but not saved yet).

5 Press [Exit].

⇒ Yes is highlighted.

Logger 4.1.3
Log inte Save ?
Clear lo Yes
No

6 Press [Enter] to save the new parameter.

⇒ The system reboots, the new parameter is set.

Changing values

Alarm oxygen 5.3.1.1.1
Alarm High 10.00 ppm
Alarm Low 1.00 ppb
Hysteresis 0.10 ppb
Delay 5 Sec

1 Select the value you want to change.

2 Press [Enter].

3 Set required value with [▲] or [▼] key.

Alarm oxygen 5.3.1.1.1
Alarm High 8.00 ppb
Alarm Low 1.00 ppb
Hysteresis 0.10 pp
Delay 5 Sec

4 Press [Enter] to confirm the new value.

5 Press [Exit].

⇒ Yes is highlighted.

6 Press [Enter] to save the new value.

6. Maintenance

Maintenance frequency depends strongly on the water quality. The AMI INSPECTOR Oxygen is designed for determination of low level of dissolved oxygen in high purity water.

It is not suitable for the measurement of dissolved oxygen in waste water.

6.1. Maintenance Table

Monthly	If necessary, perform an air calibration.
Half-yearly	Clean Swansensor Oxytrace G membrane with a soft tissue.
Yearly	If necessary, replace filling electrolyte. If the sensor is exposed to air frequently during long time intervals, the electrolyte and membrane may have to be changed earlier (see below*). Clean flow cell and flow meter, if dirty.
Every 2nd year	Replace Swansensor Oxytrace G membrane by using a new, prefilled sensor cap.

*A change of membrane and electrolyte is recommended:

- ♦ if indicated in the maintenance list (remaining amount <10%)
- ♦ if the response of the sensor is slow
- ♦ if the sensor can not be calibrated any more and/or the instrument shows a corresponding error message
- ♦ if the sensor signal is very unstable.

6.2. Stop of Operation for Maintenance

- 1 Shut off power of the instrument.
- 2 Stop sample flow by closing the flow regulating valve.

6.3. Maintenance of the Oxygen Sensor



WARNING


Etching liquid

The electrolyte is alkaline and caustic. It contains less than 1% of potassium hydroxide.

- ♦ Do not ingest. Wear protective goggles and gloves during handling. Avoid contact with clothes.
- ♦ In case of accidental contact with the eyes, wash immediately with clear water and contact a physician. Show him the label of the bottle or this section of the manual.
- ♦ Short contact with skin is harmless, nevertheless wash with lots of water.


6.3.1 Electrolyte exchange

An electrolyte exchange is indicated in the maintenance list as soon as the remaining amount is below 10%.



- A** Fixing sleeve
B Sensor
C Flow cell

- 1 Unscrew the fixing sleeve [A].
- 2 Remove the sensor from the flow cell.



- 3 Unscrew and remove the sensor cap [H] from the Swansensor Oxytrace G [A].
- 4 Empty the remaining electrolyte.
- 5 Refill the sensor cap with fresh electrolyte.

NOTICE: There is a groove [C] in the thread [B] of the sensor, where excessive air and electrolyte can escape while screwing the sensor cap onto the sensor. Hold the sensor in vertical position, measuring head pointing downwards.

- 6 Slowly screw the sensor cap onto the sensor to allow the excess electrolyte to escape without building up too much pressure inside the electrode. Fasten sensor cap tightly.
- 7 Clean the sensor thoroughly and dry the sensing membrane with a soft tissue.
- 8 Switch on power.
- 9 Let the sensor run-in at air for at least 30 min, better 1 h.
- 10 Afterwards perform an air calibration.
- 11 Install the sensor into the flow cell.
- 12 Select "New Filling" to reset the counter for remaining electrolyte, see <Maintenance>/<Service> 3.2.1, p. 52).

6.3.2 Clean Swansensor Oxytrace and G Flow Cell

Depending on the water quality, the Swansensor Oxytrace G and the flow cell will necessitate a cleaning.

Before cleaning, stop operation as described in [Stop of Operation for Maintenance](#), p. 28.

- 1 Dismount the Swansensor Oxytrace G, see [Electrolyte exchange](#), p. 29.
- 2 Clean the sensor with a soft tissue and rinse it with water afterwards.
- 3 Use a soft brush to remove the dirt which sticks on the walls of the flow cell.
- 4 Flush the flow cell with clean water.
- 5 Install the Swansensor Oxytrace G and start sample flow.

6.4. Calibration

The sensing part of the sensor must not be in direct contact with water!


In the wet flow cell, the atmosphere will be saturated with water vapor. This atmosphere will produce the most accurate calibration results.

The required time for a calibration depends mainly on the difference between temperature and oxygen content in the sample and in the air. It can take 15 – 20 minutes. This is also the case, if the electrolyte was exchanged.

As soon as the reading is stable, the microprocessor will store the calibration data in the memory. The end of the calibration is indicated on the display.

To perform a calibration proceed as follows:

- 1 Navigate to menu <Maintenance>/<Calibration>.
- 2 Press [Enter] to start the calibration and follow the dialog on the display.




Calibration 3.1.5

Close regulating valve
to turn off sample flow.

<Enter> to continue

- 3 Stop the sample flow by closing the flow regulating valve.



Calibration 3.1.5

Take sensor out of
flow cell and dry
membrane and sensor


<Enter> to continue

- 4 Unscrew and remove the threaded sleeve [A], see [Electrolyte exchange, p. 29](#).
- 5 Remove the oxygen sensor [B] from the flow cell [C].
- 6 Dry the sensor membrane and the flow cell with a soft paper tissue.

Calibration 3.1.5

Place the electrode into the wet flow cell at a slightly tilted angle.

<Enter> to continue



A Tilted sensor

B Flow cell

Calibration 3.1.1

Saturation 98.7 %
Sat. Current 32 μ A

Progress



Calibration 3.1.1

Saturation 98.7 %
Sat. Current 32 μ A

Calibration Successful

- 7 Press [Enter] to start the calibration measurement.

⇒ The saturation should reach 100%, the saturation current should be about 22 μ A to 33 μ A. If the measuring values are not stable during the measuring period, the calibration will be discarded.

- 8 Press [Enter] to confirm the calibration.

6.5 Zero-Verification

Swansensor Oxytrace G for the measurement of low oxygen content (< 1 ppb).

- 1 Calibrate the sensor according to chapter [Calibration, p. 32](#).
- 2 Prepare a 5%-sodium sulfite solution with demineralized water.
- 3 Put the electrode into the sodium sulfite solution afterwards. Assure that there are no air bubbles in front of the sensor.
- 4 The measured value should now be < 1 ppb.

NOTICE: Depending on the state of the electrode this process can take several hours. In case of an electrode-refill, this can take days until the measured value is lower than 1 ppb.

6.6. Quality Assurance of the Instrument

Every SWAN on-line instrument is equipped with integrated, autonomous quality assurance functions to survey the plausibility of each measurement.

For the AMI Oxytrace / AMI Oxytrace QED these are:

- ♦ continuous monitoring of sample flow
- ♦ continuous monitoring of the temperature inside the transmitter case
- ♦ periodic accuracy test with ultra high precision resistors

Further a manual, menu driven inspection procedure can be carried out using a certified reference instrument. Running at the same sampling point as an inspection equipment, the AMI Inspector Oxygen verifies the measuring results. After enabling the quality assurance procedure by defining the quality assurance level, the instrument reminds the user periodically to run the procedure and results are stored in a history for review.

Quality assurance level

Central feature of the quality assurance function is the assignment of the monitored process to a Quality assurance level.

There are three predefined levels plus a user level. Hereby the inspection interval, the deviation limits of temperature and measuring result between the inspection equipment and the monitoring instrument are defined.

- ♦ Level 1: **Trend**; Measurement used as an additional information to follow the process indicating trends.
- ♦ Level 2: **Standard**; Monitoring of several parameters of a process (e.g. oxygen, saturation). In case of instrument failure, other parameters can be used for process monitoring.
- ♦ Level 3: **Crucial**; Monitoring of critical processes, value is used for control of another part or subsystem (valve, dosing unit, etc.).

Additional level:

- ♦ Quality level 4: **User**; User defined inspection interval, maximal deviation of temperature and measuring result.

Quality Level	max. deviation temperature [°C] ^{a)}	max. deviation result [%]	min. inspection interval
0: Off	Off	Off	Off
1: Trend	0.5 °C	10 %	annual
2: Standard	0.4 °C	5 %	quarterly
3: Crucial	0.3 °C	5 %	monthly
4: User	0 - 2 °C	0 - 20%	annual, quarterly, monthly

a) sample temperature must be 25 °C +/-5 °C.

Procedure The standard workflow includes the following steps:

- 1 Activate SWAN Quality assurance procedure
- 2 Pre-test
- 3 Connect instruments
- 4 Carry out comparison measurement
- 5 Completion of the measurement

NOTICE: The procedure should only be carried out through qualified personnel.

6.6.1 Activate SWAN Quality assurance procedure

Enable quality assurance procedure on the process monitor(s) which shall be checked by selecting the quality level in menu 5.1.2.1. The corresponding sub menus are then activated.

NOTICE: *The activation is necessary the first time only.*

6.6.2 Pre-test

- ♦ Reference instrument: AMI Inspector Oxygen:
 - Check certificate; reference instrument certificate not older than one year.
 - Check battery; Battery of the AMI Inspector Oxygen should be completely charged. Remaining operating time on display minimum 20 hours.
 - Sensor is in working condition
- ♦ On-line instrument: Monitor AMI Oxytrace:
 - Good order and condition; Flow cell free of particles, Sensor surface free of deposits.
 - Check message list; Review the message list in menu 1.3 and check for frequently occurring alarms (as for example flow alarms). If alarms occur frequently remove cause before starting the procedure.

6.6.3 Connect the sample lines

See corresponding chapter in the manual of the process monitor which shall be checked with a reference instrument.


The choice of sampling depends strongly on local conditions on site. Possible sampling:

- ♦ via sample point,
- ♦ via T-fitting or
- ♦ via piggyback/downstream

NOTICE:

- *avoid ingress of air, use screwed fitting,*
- *sample as near as possible to the process monitor,*
- *wait approx. 10 minutes, whilst measurement is running, until measurement value and temperature are stabilized.*

Example As an example following picture shows the connection of the reference instrument via T-fitting to the process monitor.



- | | |
|-------------------------------|------------------------|
| A Monitor AMI Oxytrace | E Sample outlet |
| B AMI Inspector Oxygen | F Sample inlet |
| C Reference flow cell | G T-fitting |
| D On-line flow cell | |

- 1 Stop sample flow to the monitor AMI Oxytrace by closing the appropriate valve, e.g. back pressure regulator, sample preparation or flow regulating valve at flow cell.
- 2 Connect sample line of the monitor AMI Oxytrace [A] with the sample inlet of the reference instrument AMI Inspector Oxygen [B]. Use the supplied tube made of PA.
- 3 Connect sample outlet of the reference instrument AMI Inspector Oxygen to the sample outlet funnel of the monitor.
- 4 Switch on the AMI Inspector Oxygen. Open the flow regulating valve and regulate the sample flow to 10 l/h. The actual flow is shown on the transmitter.

6.6.4 Carry out comparison measurement

Start by selecting Quality Assurance in menu 3.5 of the monitor AMI Oxytrace.

1 Navigate to menu Maintenance /Quality Assurance.

2 Press [Enter].

3 Follow the dialog on the Display.

Quality Assurance	3.5.5
- Carry out preparations	
- Install Inspector	
- Sample flow to 10 l/h	

<Enter> to continue	

Quality Assurance	3.5.5
Value O2	0.05 ppb
Value Temp.	25.00 °C
Wait 10 Minutes	

<Enter> to continue	

Quality Assurance	3.5.3
Value O2	0.05 ppb
Value Temp.	25.00 °C
Inspector O2	0.06 ppb
Inspector Temp.	25.0 °C

<Enter> to continue	

Quality Assurance	3.5.4
Value O2	0.05 ppb
Value Temp.	25.00 °C
Inspector	0.06 ppm
Inspector Temp.	25.0 °C

<Enter> to continue	

Quality Assurance	3.5.5
Max. Dev. O2	0.5 %
Max. Dev. Temp.	0.4 °C
Dev. O2	0.1 %
Dev. Temp.	0.4 °C

QA-Check succesful	

4 Carry out pre test preparations
Connect instruments.
Regulate sample flow to 10 l/h using the appropriate valve.

5 Wait 10 minutes whilst measurement is running.
Press [Enter] to continue.

6 Read the ppb value of the reference instrument and enter under "Inspector." by using the [▲] or [▼] keys.

7 Press [Enter] to confirm.

8 Read temperature value of the reference instrument and enter under "Inspector Temp." by using the [▲] or [▼] keys.

9 Press [Enter] to confirm.

10 Press [Enter] to continue.

⇒ The results are saved in QA-History regardless if successful or not

6.6.5 Completion of the measurement

- 1 Stop the sample flow to the AMI Oxytrace by closing the appropriate valve, e.g. back pressure regulator, sample preparation or flow regulating valve at flow cell again.
- 2 Close flow regulating valve of the AMI Inspector.
- 3 Disconnect the AMI Inspector by removing the tubes and connect the sample outlet of the Monitor AMI Oxytrace to the sample outlet funnel again.
- 4 Start sample flow again and regulate sample flow.
- 5 Shutdown the AMI Inspector Oxygen.

If the instrument will not be used for a longer period of time, see [Longer Stop of Operation, p. 41](#).

6.7. Replacing Fuses



WARNING


External Voltage.

External supplied devices connected to relay 1 or 2 or to the alarm relay can cause electrical shocks.

- ♦ Make sure that the devices connected to the following contacts are disconnected from the power before continuing the installation.
 - relay 1
 - relay 2
 - alarm relay


Find and repair the cause for the short circuit before replacing the fuse. Use tweezers or needle-nosed pliers to remove the defective fuse.

Use original fuses provided by SWAN only.



A 1.25 AF/250V Instrument power supply

6.8. Replacing the Battery



- 1 Switch the AMI Inspector off.
- 2 If connected, disconnect the power adapter from the power jack.
- 3 Open the transmitter housing.
- 4 Pull out the ribbon cable [C] from the mainboard.
- 5 Disconnect battery plug [B] and replace the battery.

6.9. Longer Stop of Operation

- 1 Shut off power of the instrument.
- 2 Stop sample flow.
- 3 Remove the Swansensor Oxytrace G.
- 4 Clean the sensor with a soft tissue and rinse it with water afterwards.
- 5 Use a soft brush to remove the dirt which sticks on the walls of the flow cell.
- 6 Fill the flow cell with water.
- 7 Install the Swansensor Oxytrace G.

7. Error List

Error

Non-fatal Error. Indicates an alarm if a programmed value is exceeded.

Such Errors are marked **E0xx** (bold and black).




Fatal Error (blinking symbol)

Control of dosing devices is interrupted.

The indicated measured values are possibly incorrect.

Fatal Errors are divided in the following two categories:

- Errors which disappear if correct measuring conditions are recovered (i.e. Sample Flow low).
Such Errors are marked **E0xx** (bold and orange)
- Errors which indicate a hardware failure of the instrument.
Such Errors are marked **E0xx** (bold and red)



Error or fatal Error

Error not yet acknowledged.

Check **Pending Errors 1.1.5 *** and take corrective action.

Press [ENTER].

Navigate to menu <Messages>/<Pending Errors>.

Press [ENTER] to acknowledge the Pending Errors. The Error is reset and saved in the Message List.

Error	Description	Corrective action
E001	oxygen Alarm high	– check process – check programmed value, see 5.3.1.1.1, p. 59
E002	oxygen Alarm low	– check process – check programmed value, see 5.3.1.1.25, p. 59
E003	Saturation Alarm high	– check process – check programmed value, see 5.3.1.4, p. 60
E004	Saturation Alarm low	– check process – check programmed value, see 5.3.1.4, p. 60
E007	Sample Temp. high	– check process – check programmed value, see 5.3.1.3.1, p. 60
E008	Sample Temp. low	– check process – check programmed value, see 5.3.1.3.22, p. 60
E009	Sample Flow high	– check sample flow – check programmed value, see 5.3.1.2.2, p. 60
E010	Sample Flow low	– establish sample flow – clean instrument – check programmed value, see 5.3.1.2.32, p. 60
E011	Temp. shorted	– Check wiring of sensor – Check sensor
E012	Temp. disconnected	– Check wiring of sensor – Check sensor

AMI INSPECTOR Oxygen

Error List

Error	Description	Corrective action
E013	Case Temp. high	– check case/environment temperature – check programmed value, see 5.3.1.5.1, p. 61
E014	Case Temp. low	– check case/environment temperature – check programmed value, see 5.3.1.5.2, p. 61
E017	Control Timeout	– check control device or programming in Installation, Relay contact, Relay 1/2 see 5.3.2 and 5.3.3, p. 61
E024	Input active	– See If Fault Yes is programmed in Menu see 5.3.4, p. 65
E026	IC LM75	– call service
E030	EEProm Frontend	– call service
E031	Calibration Recout	– call service
E032	Wrong Frontend	– call service
E033	Power-on	– none, normal status
E034	Power-down	– none, normal status
E065	Electrolyte depleted	– Refill electrolyte, see Electrolyte exchange, p. 29

8. Program Overview

For explanations about each parameter of the menus see [Program List and Explanations](#), p. 50.

- ♦ Menu 1 **Messages** informs about pending errors and maintenance tasks and shows the error history. Password protection possible. No settings can be modified.
- ♦ Menu 2 **Diagnostics** is always accessible for everybody. No password protection. No settings can be modified.
- ♦ Menu 3 **Maintenance** is for service: Calibration, simulation of outputs and set time/date. Please protect with password.
- ♦ Menu 4 **Operation** is for the user, allowing to set limits, alarm values, etc. The presetting is done in the menu Installation (only for the System engineer). Please protect with password.
- ♦ Menu 5 **Installation**: Defining assignment of all inputs and outputs, measuring parameters, interface, passwords, etc. Menu for the system engineer. Password strongly recommended.

8.1. Messages (Main Menu 1)

Pending Errors 1.1*	Pending Errors	1.1.5*
Maintenance List 1.2*	Maintenance List	1.2.5*
Message List 1.3*	Number Date, Time	1.3.1*

* Menu numbers

8.2. Diagnostics (Main Menu 2)

Identification	Desig.	AMI Oxytrace	* Menu numbers	
2.1*	Version	6.00-11/15		
	Factory Test	Instrument	2.1.3.1*	
	2.1.3*	Motherboard		
		Front End		
	Operating Time	Years / Days / Hours / Minutes / Seconds	2.1.4.1*	
	2.1.4*			
Sensors	Sensor	Current Value		
2.2*	2.2.1*	(Raw value tc)		
		(Raw value)		
		Saturation		
		Cal. History	Number	2.2.1.5.1*
		2.2.1.5*	Date, Time	
			Sat. Current	
			Air pressure	
	Miscellaneous	Case Temp.	2.2.2.1*	
	2.2.2*	Air pressure		
Sample	Sample ID	2.3.1*		
2.3*	Temperature °C			
	Nt5K Ohm			
I/O State	Alarm Relay	2.4.1*		
2.4*	Relay 1/2	2.4.2*		
	Input			
	Signal Output 3			
Interface	Protocol	2.5.1*		
2.5*	USB Stick			

8.3. Maintenance (Main Menu 3)

Calibration	Calibration	3.1.5	* Menu numbers
3.1*			
Service	Electrolyte	Last filling	
3.2*	3.2.1*	Remaining amount	
		Remaining time	
		New Filling	3.2.1.5*
Simulation	Alarm Relay	3.3.1*	
3.3*	Relay 1	3.3.2*	
	Relay 2	3.3.3*	
	Signal Output 3	3.3.6*	
Set Time	(Date), (Time)		
3.4*			

8.4. Operation (Main Menu 4)

Sensors	Filter Time Const.	4.1.1*		
4.1*	Hold after Cal.	4.1.2*		
Relay Contacts	Alarm Relay	Alarm Oxygen	Alarm High	4.2.1.1.1*
4.2*	4.2.1*	4.2.1.1*	Alarm Low	4.2.1.1.22*
			Hysteresis	4.2.1.1.32*
			Delay	4.2.1.1.42*
		Alarm Saturation	Alarm High	4.2.1.2.1*
		4.2.1.2*	Alarm Low	4.2.1.2.22*
			Hysteresis	4.2.1.2.32*
			Delay	4.2.1.2.42*
	Relay 1/2	Setpoint	4.2.x.100*	
	4.2.2* - 4.2.3*	Hysteresis	4.2.x.200*	
		Delay	4.2.x.30*	
	Input	Active	4.2.4.1*	
	4.2.4*	Signal Outputs	4.2.4.2*	
		Output / Control	4.2.4.3*	
		Fault	4.2.4.4*	
		Delay	4.2.4.5*	
Logger	Log Interval	4.3.1*		
4.3*	Clear Logger	4.3.2*		* Menu numbers
	Eject USB Stick	4.3.3*		

8.5. Installation (Main Menu 5)

Sensors	Miscellaneous	Flow	5.1.1.1*	* Menu numbers
5.1*	5.1.1*	Offset	5.1.1.2*	
Signal Outputs	Signal Output 3	Parameter	5.2.1.1	
5.2*	5.2.1*	Current Loop	5.2.1.2*	
		Function	5.2.1.3*	
		Scaling	Range Low	5.2.1.40.10*
		5.2.1.40	Range High	5.2.1.40.20*
Relay Contacts	Alarm Relay	Alarm oxygen	Alarm High	5.3.1.1.1*
5.3*	5.3.1*	5.3.1.1*	Alarm Low	5.3.1.1.22
			Hysteresis	5.3.1.1.32
			Delay	5.3.1.1.42

Table with 4 columns: Main Category, Sub-Category, Item Name, and Item Number. Rows include sections like Sample Flow, Sample Temp., Alarm Saturation, Case Temp., Relay 1/2, Input, Miscellaneous, and Interface.

* Menu numbers

9. Program List and Explanations

1 Messages

1.1 Pending Errors

- 1.1.5 Provides the list of active errors with their status (active, acknowledged). If an active error is acknowledged, the alarm relay is active again. Cleared errors are moved to the Message list.

1.2 Maintenance List

- 1.2.5 Provides the list of necessary maintenance. Cleared maintenance messages are moved to the Message list.

1.3 Message List

- 1.3.1 Shows the error history: Error code, date / time of issue and status (active, acknowledged, cleared). 65 errors are memorized. Then the oldest error is cleared to save the newest error (circular buffer).

2 Diagnostics

In diagnostics mode, the values can only be viewed, not modified.

2.1 Identification

Desig.: Designation of the instrument.

Version: Firmware of instrument (e.g. V6.00-11/15)

- 2.1.3 **Factory Test:** Test date of the Instrument, Motherboard and Frontend.

- 2.1.4 **Operating Time:** Shows the operating time in Years, Days, Hours, Minutes and Seconds.

2.2 Sensors

- 2.2.1 Oxytrace G

Current value: Shows the actual measuring value in ppb.

Raw value tc: Shows the actual temperature compensated measuring value in mA.

Saturation Shows the actual saturation in %

2.2.1.4 Cal. History

Review the diagnostic values of the last calibration of the oxygen sensor. Max. 64 data records are memorized.

Number: Calibration counter.

Date, Time: Date and time of the calibration.

Sat. Current: Saturation current at that time of calibration.

Air pressure: Air pressure at that time of calibration.

2.2.2 Miscellaneous:

2.2.2.1 *Case Temp:* Shows the actual temperature in °C inside the transmitter.

Air pressure: Shows the actual air pressure in hPa

2.3 Sample

2.3.1 *Sample ID:* Shows the assigned sample identification. This identification is defined by the user to identify the location of the sample

Temperature: Shows temperature in °C.

(Nt5K): Shows raw value of the temperature in Ω.

Sample Flow: Shows the sample flow in l/h

(Raw value) Shows the sample flow in Hz

2.4 I/O State

Shows actual status of all in- and outputs.

2.4.1

Alarm Relay: Active or inactive

Relay 1 and 2: Active or inactive

Input: Open or closed.

Signal Output 3: Actual current in mA

2.5 Interface

2.5.1 Protocol USB Stick.

3 Maintenance

3.1 Calibration

- 3.1.1 Start a calibration and follow the instructions on the screen. Displayed values are saturation in % and the saturation current in mA. The indication bar shows the progress. Detailed explanation see [Calibration, p. 32.](#)

3.2 Service

3.2.1 Electrolyte

Last Filling: Shows the date of the last filling of electrolyte.

Remaining Amount: Remaining amount of electrolyte in %.

Remaining Time: Remaining time in days until electrolyte exchange recommended.

- 3.2.1.5 *New Filling:* Select "Yes" after electrolyte exchange to reset the counter.

3.3 Simulation

To simulate a value or a relay state, select the

- ♦ alarm relay
- ♦ relay 1 and 2
- ♦ signal output 3 (signal outputs 1 and 2 are deactivated)

with the [▲] or [▼] keys.

Press the [Enter]> key.

Change the value with the [▲] or [▼] keys.

Press the [Enter] key.

⇒ *The value is simulated by the relay/signal output.*

Alarm Relay: Active or inactive

Relay 1: Active or inactive

Relay 2: Active or inactive

Signal Output 3: Current in mA

At the absence of any key activities, the instrument will switch back to normal mode after 20 min. If you quit the menu, all simulated values will be reset.

3.4 Set Time

Adjust date and time.

4 Operation

4.1 Sensors

- 4.1.1 *Filter Time Constant:* Used to damp noisy signals. The higher the filter time constant, the slower the system reacts to changes of the measured value.
Range: 5–300 Sec
- 4.1.2 *Hold after Cal:* Delay permitting the instrument to stabilize again after calibration. During calibration plus hold-time, the signal outputs are frozen (held on last valid value), alarm values, limits are not active.
Range: 0–6'000 Sec

4.2 Relay Contacts

See [Relay Contacts](#), p. 21

4.3 Logger

The instrument is equipped with an internal logger. The data can be copied to the USB stick installed in the transmitter.
The logger can save approx. 1500 data records. The Records consists of: Date, time, alarms, measuring values, raw values, case temperature, flow.

- 4.3.1 *Log Interval:* Select a convenient log interval. Consult the table below to estimate the max logging time. When the logging buffer is full, the oldest data record is erased to make room for the newest one (circular buffer).
Range: 1 Second to 1 hour

Interval	1 s	5 s	1 min	5 min	10 min	30 min	1 h
Time	25 min	2 h	25 h	5 d	10 d	31 d	62 d

- 4.3.2 *Clear Logger:* If confirmed with **yes**, the complete logger data is deleted. A new data series is started.
- 4.3.3 *Eject USB Stick*
With this function all logger data are copied to the USB stick before the USB stick is deactivated.

5 Installation

5.1 Sensors

5.1.1 Miscellaneous

5.1.1.1 *Flow*: If a flow cell without flow measurement (e.g. B-Flow) is used, choose none. With flow measurement select Q-Flow

5.1.1.2 *O2 Offset*: Manual, small correction of the offset.
Range -5 to +5 ppb.

5.1.2 Quality Assurance

Not applicable.

5.2 Signal Outputs

5.2.1 Signal Output 3 (signal outputs 1 and 2 are deactivated)

5.2.1.1 *Parameter:* Assign one of the process values to the signal output.
Available values:

- ♦ Oxygen
- ♦ Temperature
- ♦ Sample Flow (if a flow sensor is selected)
- ♦ Saturation


5.2.1.2 *Current Loop:* Select the current range of the signal output.
Make sure the connected device works with the same current range.
Available ranges: 0–20 mA or 4–20 mA

5.2.1.3 *Function:* Define if the signal output is used to transmit a process value or to drive a control unit. Available functions are:

- ♦ Linear, bilinear or logarithmic for process values.
See [As process values, p. 55](#)
- ♦ Control upwards or control downwards for controllers.
See [As control output, p. 57](#)

As process values


The process value can be represented in 3 ways: linear, bilinear or logarithmic. See graphs below.



A linear

B bilinear

x Measured value



X Measured value (logarithmic)

5.2.1.40 **Scaling:** Enter beginning and end point (Range low & high) of the linear or logarithmic scale. In addition, the midpoint for the bilinear scale.

Parameter: Oxygen.

Range low: 0.00 ppb–20.00 ppm

Range high: 0.00 ppb–20.00 ppm

Parameter: Temperature

Range low: -30 to + 130 °C

Range high: 30 to + 130 °C

Parameter: Sample flow

Range low: 0–50 l/h

Range high: 0–50 l/h

Parameter: Saturation

Range low: 0–200 %

Range high: 0–200 %


As control output

Signal outputs can be used for driving control units. We distinguish different kinds of controls:

- ♦ *P-controller*: The controller action is proportional to the deviation from the setpoint. The controller is characterized by the P-Band. In the steady-state, the setpoint will never be reached. The deviation is called steady-state error.
Parameters: setpoint, P-Band
- ♦ *PI-controller*: The combination of a P-controller with an I-controller will minimize the steady-state error. If the reset time is set to zero, the I-controller is switched off.
Parameters: setpoint, P-Band, reset time.
- ♦ *PD-controller*: The combination of a P-controller with a D-controller will minimize the response time to a fast change of the process value. If the derivative time is set to zero, the D-controller is switched off.
Parameters: setpoint, P-Band, derivative time.
- ♦ *PID-controller*: The combination of a P-, an I - and a D-controller allows a proper control of the process.
Parameters: setpoint, P-Band, reset time, derivative time.

Ziegler-Nichols method for the optimization of a PID controller:

Parameters: Setpoint, P-Band, Reset time, Derivative time



- | | | |
|----------|------------------------------------|--------------|
| A | Response to maximum control output | $Xp = 1.2/a$ |
| B | Tangent on the inflection point | $Tn = 2L$ |
| X | Time | $Tv = L/2$ |

The point of intersection of the tangent with the respective axis will result in the parameters a and L.

Consult the manual of the control unit for connecting and programming details. Choose control upwards or downwards.

Setpoint: User-defined process value for the selected parameter.

P-Band: Range below (upwards control) or above (downwards control) the set-point, within which the dosing intensity is reduced from 100% to 0% to reach the set-point without overshooting.

- 5.2.1.43 Control Parameters:** if Parameter = Oxygen
- 5.2.1.43.10 Setpoint:
Range: 0.00 ppb–20.00 ppm
- 5.2.1.43.20 P-Band:
Range: 0.00 ppb–20.00 ppm
- 5.2.1.43 Control Parameters:** if Parameter = Temperature
- 5.2.1.43.11 Setpoint:
Range: -30 to + 130 °C
- 5.2.1.43.21 P-Band:
Range: 0 to + 100 °C
- 5.2.1.43 Control Parameters:** if Parameter = Sample flow
- 5.2.1.43.12 Setpoint:
Range: 0–50 l/h
- 5.2.1.43.22 P-Band:
Range: 0–50 l/h
- 5.2.1.43 Control Parameters:** if Parameter = Saturation
- 5.2.1.43.13 Setpoint:
Range: 0–200%
- 5.2.1.43.23 P-Band:
Range: 0–200%
- 5.2.1.43.3 *Reset time:* The reset time is the time till the step response of a single I-controller will reach the same value as it will be suddenly reached by a P-controller.
Range: 0–9'000 sec
- 5.2.1.43.4 *Derivative time:* The derivative time is the time till the ramp response of a single P-controller will reach the same value as it will be suddenly reached by a D-controller.
Range: 0–9'000 sec
- 5.2.1.43.5 *Control timeout:* If a controller action (dosing intensity) is constantly over 90% during a defined period of time and the process value does not come closer to the setpoint, the dosing process will be stopped for safety reasons.
Range: 0–720 min

5.3 Relay Contacts

- 5.3.1 Alarm Relay:** The alarm relay is used as cumulative error indicator. Under normal operating conditions the contact is active.

The contact is inactive at:

- ♦ Power loss
- ♦ Detection of system faults like defective sensors or electronic parts
- ♦ High case temperature
- ♦ Process values out of programmed ranges.

Program alarm levels for the following parameters:

- ♦ Meas. Value
- ♦ Temperature
- ♦ Sample Flow (if a flow sensor is selected)
- ♦ Case Temperature high
- ♦ Case Temperature low

5.3.1.1 Alarm Oxygen

- 5.3.1.1.1 **Alarm High:** If the measured value rises above the alarm high value, the alarm relay is activated and E001, is displayed in the message list.

Range: 0.00 ppb–20.00 ppm

- 5.3.1.1.25 **Alarm Low:** If the measured value falls below the alarm low value, the alarm relay is activated and E002 is displayed in the message list.

Range: 0.00 ppb–20.00 ppm

- 5.3.1.1.35 **Hysteresis:** Within the hyst. range, the relay does not switch. This prevents damage of relays contacts when the measured value fluctuates around the alarm value.

Range: 0.00 ppb–20.00 ppm

- 5.3.1.1.45 **Delay:** Duration, the activation of the alarm relay is retarded after the measuring value has risen above/fallen below the programmed alarm.

Range: 0–28'800 Sec

5.3.1.2 Sample Flow: Define at which sample flow a flow alarm should be issued.

5.3.1.2.1 *Flow Alarm:* Program if the alarm relay should be activated if there is a flow alarm. Choose between yes or no. The flow alarm will always be indicated in the display, pending error list, saved in the message list and the logger.
Available values: Yes or no

NOTICE: *Sufficient flow is essential for a correct measurement. We recommend to program yes.*

5.3.1.2.2 *Alarm High:* If the measuring values rises above the programmed value E009 will be issued.
Range: 12–50 l/h

5.3.1.2.32 *Alarm Low:* If the measuring values falls below the programmed value E010 will be issued.
Range: 8–11 l/h

5.3.1.3 Sample Temp.: Define at which sample temperature an alarm should be issued.

5.3.1.3.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay is activated and E007 is issued.
Range: 30–100 °C

5.3.1.3.22 *Alarm Low:* If the measured value rises above the alarm high value, the alarm relay is activated and E008 is issued.
Range: -10 to + 20 °C

5.3.1.4 Alarm Saturation

5.3.1.4.1 *Alarm High:* If the measured value rises above the alarm high value, the alarm relay is activated and E001, is displayed in the message list.
Range: 0.00–200 %

5.3.1.4.22 *Alarm Low:* If the measured value falls below the alarm low value, the alarm relay is activated and E002 is displayed in the message list.
Range: 0.00–200 %

5.3.1.4.32 *Hysteresis:* Within the hyst. range, the relay does not switch. This prevents damage of relays contacts when the measured value fluctuates around the alarm value.
Range: 0.00–200 %

5.3.1.4.42 *Delay:* Duration, the activation of the alarm relay is retarded after the measuring value has risen above/fallen below the programmed alarm.
Range: 0–28'800 Sec

5.3.1.5 Case Temp.

5.3.1.5.1 *Case Temp. high:* Set the alarm high value for temperature of electronics housing. If the value rises above the programmed value E013 is issued.
Range: 30–75 °C

5.3.1.5.2 *Case Temp. low:* Set the alarm low value for temperature of electronics housing. If the value falls below the programmed value E014 is issued.
Range: -10 to + 20 °C

5.3.2 and 5.3.3 Relay 1 and 2: The function of relay contacts 1 or 2 are defined by the user

NOTICE: *The navigation in the menu <Relay 1> and <Relay 2> is equal. For reason of simplicity only the menu numbers of Relay 1 are used in the following.*

- 1 First select the functions as:
 - Limit upper/lower,
 - Control upwards/downwards,
 - Timer
 - Fieldbus
- 2 Then enter the necessary data depending on the selected function. The same values may also be entered in menu [4.2 Relay Contacts](#), p. 53

5.3.2.1 Function = Limit upper/lower:

When the relays are used as upper or lower limit switches, program the following:

5.3.2.20 *Parameter:* choose one of the following process values

- ♦ Oxygen
- ♦ Temperature
- ♦ Sample Flow
- ♦ Saturation

5.3.2.300 *Setpoint:* If the measured value rises above respectively falls below the set-point, the relay is activated.

Parameter	Range
Oxygen	0.00 ppb–20.00 ppm
Temperature	-30 to + 130 °C
Sample flow	0–50 l/h
Saturation	0–200 %

5.3.2.400 *Hysteresis*: within the hysteresis range, the relay does not switch. This prevents damage of relay contacts when the measured value fluctuates around the alarm value.

Parameter	Range
Oxygen	0.00 ppb–20.00 ppm
Temperature	0–100 °C
Sample flow	0–50 l/h
Saturation	0–200 %

5.3.2.50 *Delay*: Duration, the activation of the alarm relay is retarded after the measuring value has risen above/fallen below the programmed alarm.
Range. 0–600 Sec

5.3.2.1 Function = Control upwards/downwards

The relays may be used to drive control units such as solenoid valves, membrane dosing pumps or motor valves. When driving a motor valve both relays are needed, relay 1 to open and relay 2 to close the valve.

5.3.2.22 *Parameter*: choose one of the following process values

- ♦ Oxygen
- ♦ Temperature
- ♦ Sample Flow
- ♦ Saturation

5.3.2.32 Settings

Choose the respective actuator:

- ♦ Time proportional
- ♦ Frequency
- ♦ Motor valve

Actuator = Time proportional

Examples of metering devices that are driven time proportional are solenoid valves, peristaltic pumps.

Dosing is controlled by the operating time.

5.3.2.32.20 *Cycle time*: duration of one control cycle (on/off change).
Range: 0–600 sec.

5.3.2.32.30 *Response time*: Minimal time the metering device needs to react.
Range: 0–240 sec.

5.3.2.32.4 Control Parameters:

Range for each Parameter same as [5.2.1.43, p. 58](#)

Actuator = Frequency

Examples of metering devices that are pulse frequency driven are the classic membrane pumps with a potential free triggering input. Dosing is controlled by the repetition speed of dosing shots.

- 5.3.2.32.21 *Pulse frequency*: Max. pulses per minute the device is able to respond to. Range: 20–300/min.

5.3.2.32.31 Control Parameters:

Range for each Parameter same as [5.2.1.43, p. 58](#)

Actuator = Motor valve

Dosing is controlled by the position of a motor driven mixing valve.

- 5.3.2.32.22 *Run time*: Time needed to open a completely closed valve
Range: 5–300 Sec.

- 5.3.2.32.32 *Neutral zone*: Minimal response time in % of the runtime. If the requested dosing output is smaller than the response time, no change will take place.
Range: 1–20 %

5.3.2.32.4 Control Parameters:

Range for each Parameter same as [5.2.1.43, p. 58](#)

5.3.2.1 Function = Timer

The relay will be activated repetitively depending on the programmed time scheme.

- 5.3.2.24 *Mode*: Operating mode (interval, daily, weekly)

5.3.2.24 Interval

- 5.3.2.340 *Interval*: The interval can be programmed within a range of 1–1440 min.

- 5.3.2.44 *Run Time*: Enter the time the relay stays active.
Range: 5–32'400 Sec.

- 5.3.2.54 *Delay*: during run time plus the delay time the signal and control outputs are held in the operating mode programmed below.
Range: 0–6'000 Sec.

5.3.2.6 *Signal Outputs*: Select operating mode of the signal output:

Cont.: Signal outputs continue to issue the measured value.

Hold: Signal outputs hold the last valid measured value.
Measurement is interrupted. Errors, except fatal errors, are not issued.

Off: Signal outputs are switched off (set to 0 or 4 mA).
Errors, except fatal errors, are not issued.

5.3.2.7 *Output/Control*: Select operating mode of the controller output:

Cont.: Controller continues normally.

Hold: Controller continues based on the last valid value.

Off: Controller is switched off.

5.3.2.24 daily

The relay contact can be activated daily, at any time of a day.

5.3.2.341 *Start time*: to set the start time proceed as follows:

- 1 Press [Enter], to set the hours.
- 2 Set the hour with the [] or [] keys.
- 3 Press [Enter], to set the minutes.
- 4 Set the minutes with the [] or [] keys.
- 5 Press [Enter], to set the seconds.
- 6 Set the seconds with the [] or [] keys.

Range: 00:00:00–23:59:59

5.3.2.44 *Run Time*: see Interval

5.3.2.54 *Delay*: see Interval

5.3.2.6 *Signal Outputs*: see Interval

5.3.2.7 *Output/Control*: see Interval

5.3.2.24 weekly

The relay contact can be activated at one or several days, of a week. The daily starting time is valid for all days.

5.3.2.342 **Calendar:**

5.3.2.342.1 *Start time:* The programmed start time is valid for each of the programmed days. To set the start time see [5.3.2.341, p. 64](#).

Range: 00:00:00–23:59:59

5.3.2.342.2 *Monday:* Possible settings, on or off to

5.3.2.342.8 *Sunday:* Possible settings, on or off

5.3.2.44 *Run Time:* see Interval

5.3.2.54 *Delay:* see Interval

5.3.2.6 *Signal Outputs:* see Interval

5.3.2.7 *Output/Control:* see Interval

5.3.2.1 **Function = Fieldbus**

The relay will be switched via the Profibus input. No further parameters are needed.

5.3.4 Input: The functions of the relays and signal outputs can be defined depending on the position of the input contact, i.e. no function, closed or open.

5.3.4.1 *Active:* Define when the input should be active:

No: Input is never active.

When closed Input is active if the input relay is closed

When open: Input is active if the input relay is open

5.3.4.2 *Signal Outputs:* Select the operation mode of the signal outputs when the relay is active:

Cont.: Signal outputs continue to issue the measured value.

Hold: Signal outputs issue the last valid measured value.

Measurement is interrupted. Errors, except fatal errors, are not issued.

Off: Set to 0 or 4 mA respectively. Errors, except fatal errors, are not issued.

5.3.4.3 *Output/Control:* (relay or signal output):

Cont.: Controller continues normally.

Hold: Controller continues on the last valid value.

Off: Controller is switched off.

5.3.4.4 *Fault:*

No: No message is issued in pending error list and the alarm relay does not close when input is active.

Yes: Message E024 is issued and stored in the message list. The Alarm relay closes when input is active.

5.3.4.5 *Delay:* Time which the instrument waits, after the input is deactivated, before returning to normal operation.
Range: 0–6'000 Sec

5.4 Miscellaneous

- 5.4.1 *Language*: Set the desired language.
Available settings: German /English/French/Spanish
- 5.4.2 *Set defaults*: Reset the instrument to factory default values in three different ways:
- ♦ **Calibration**: Sets calibration values back to default. All other values are kept in memory.
 - ♦ **In parts**: Communication parameters are kept in memory. All other values are set back to default values.
 - ♦ **Completely**: Sets back all values including communication parameters.
- 5.4.3 *Load Firmware*: Firmware updates should be done by instructed service personnel only.
- 5.4.4 **Password**: Select a password different from 0000 to prevent unauthorized access to the menus “Messages”, “Maintenance”, “Operation” and “Installation”.
Each menu may be protected by a *different* password.
If you forgot the passwords, contact the closest SWAN representative.
- 5.4.5 *Sample ID*: Identify the process value with any meaningful text, such as KKS number.

5.5 Interface

Select one of the following communication protocols. Depending on your selection, different parameters must be defined.

5.5.1 *Protocol:* **Profibus**

- 5.5.20 Device address: Range: 0–126
- 5.5.30 ID-Nr.: Range: Analyzer; Manufacturer; Multivariable
- 5.5.40 Local operation: Range: Enabled, Disabled

5.5.1 *Protocol:* **Modbus RTU**

- 5.5.21 Device address: Range: 0–126
- 5.5.31 Baud Rate: Range: 1 200–115 200 Baud
- 5.5.41 Parity: Range: none, even, odd

5.5.1 *Protocol:* **USB-Stick:**

Only visible if an USB interface is installed. No further settings are possible.

10. Default Values

Operation:

Sensors:	Filter Time Const.:	10 Sec
	Hold after Cal.:	300 Sec
Alarm Relay		same as in Installation
Relay 1/2		same as in Installation
Input		same as in Installation
Logger:	Logger Interval:	30 Minutes
	Clear Logger:	no

Installation:

Sensors	Miscellaneous; Flow:	None
	Offset:	0.0 ppb
	Quality Assurance; Level:	0: Off
Signal Output	Parameter:	oxygen
	Current loop:	4 –20 mA
	Function:	linear
	Scaling: Range low:	0.00 ppb
	Scaling: Range high:	10.00 ppm
Alarm Relay:	Alarm oxygen; Alarm high:	10.00 ppm
	Alarm oxygen; Alarm low:	0.00 ppb
	Alarm oxygen; Hysteresis:	100 ppb
	Alarm oxygen; Delay:	5 Sec
	If Flow = Q-Flow	
	Sample Flow, Flow Alarm:	yes
	Sample Flow, Alarm high:	25.0 l/h
	Sample Flow, Alarm low:	8.0 l/h
	Sample Temp., Alarm High:	50 °C
	Sample Temp., Alarm Low:	0 °C
	Alarm Saturation; Alarm high	120 %
	Alarm Saturation; Alarm low	0.0 %
	Alarm Saturation; Hysteresis	2 %
	Alarm Saturation; Delay	5 Sec
	Case temp. high:	65 °C
	Case temp. low:	0 °C
Relay 1	Function:	limit upper
	Parameter:	oxygen
	Setpoint:	10.00 ppm
	Hysteresis:	100 ppb
	Delay:	30 Sec

AMI INSPECTOR Oxygen

Default Values



- Relay 2 Function: limit upper
 Parameter: Temperature
 Setpoint: 50 °C
 Hysteresis: 1.0 °C
 Delay: 30 Sec
- If Function = Control upw. or dnw:**
Parameter: Meas. Value
Settings: Actuator: Frequency
 Settings: Pulse Frequency: 120/min.
 Settings: Control Parameters: Setpoint: 10.00 ppm
 Settings: Control Parameters: P-band: 100 ppb
 Settings: Control Parameters: Reset time: 0 Sec
 Settings: Control Parameters: Derivative Time: 0 Sec
 Settings: Control Parameters: Control Timeout: 0 Min.
 Settings: Act. Time prop.: Cycle time: 60 s
 Settings: Act. Time prop.: Response time: 10 s
 Settings: Act. Motor valve: Run time: 60 s
 Settings: Act. Motor valve: Neutral zone: 5%
- If Function = Timer:**
Mode: Interval
 Interval: 1 min
Mode: daily
 Start time: 00.00.00
Mode: weekly
 Calendar; Start time: 00.00.00
 Calendar; Monday to Sunday: Off
Run time: 10 Sec
Delay: 5 Sec
Signal output: cont
Output/Control: cont
- Input: Active when closed
 Signal Outputs hold
 Output/Control off
 Fault no
 Delay 10 Sec

AMI INSPECTOR Oxygen

Default Values



Miscellaneous	Language:.....	English
	Set default:	no
	Load firmware:.....	no
	Password:.....	for all modes 0000
	Sample ID:.....	- - - - -
Interface	Protocol:	USB Stick

11. Index

A	
Alarm Relay	21
C	
Cable thicknesses	17
Calendar	65
Changing values	27
Charging	19
Clean Flow Cell and Swansensor Oxy- trace G	31
D	
Default Values	69
E	
Electrolyte exchange	29
Establish Sample Flow	23
external devices	19
F	
Fluidics	9
I	
Input	21
Instrument Setup	13, 38
L	
Longer Stop of Operation	41
P	
Power ON - OFF	19
Power Supply	11, 21
R	
Relay Contacts 1 and 2	22
S	
Sample requirements	11
shut-down	19
Signal Outputs	22
Software	26
T	
Temperature compensation	8
Terminals	18, 21–22
W	
Wire	17
Z	
Zero-Verification	34

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

SWAN

is represented worldwide by subsidiary companies and distributors.

cooperates with independent representatives all over the world.

SWAN Products

Analytical Instruments for:

- High Purity Water
- Feedwater, Steam and Condensate
- Potable Water
- Pool and Sanitary Water
- Cooling Water
- Waste Water and Effluents

Made in Switzerland

